


# VI-413



ZEBRA VERSION

PIN	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48
COM1	S3	S4	P1	1E	1D	1C	1B	P2	2E	2D	2C	2B	P3	3E	3D	3C	3B	P4	4E	4D	4C	4B	NC	NC	S1	A	3	S2	10	V	K	4A	4F	4G	3A	3F	3G	NC	2A	2F	2G	NC	1A	1F	1G	NC	NC	COM1

REMARKS : NC = NO CONNECTION.