

# HCD-GTR88

## SERVICE MANUAL

Ver. 1.0 2010.04

E Model  
Australian Model



Photo: HCD-GTR88 (E4 Model)

- HCD-GTR88 is the amplifier, USB, CD player, tuner and tape deck (only E4 Model) section in MHC-GTR88.

CD Section	Model Name Using Similar Mechanism	HCD-GTZ4/GTZ4i/GTZ5
	CD Mechanism Type	CDM88BL-DVBU101
	Optical Pick-up Name	KHM-313CAB/C2NP
Tape Deck Section (only for E4 Model)	Model Name Using Similar Mechanism	HCD-GT111/GT222/GT444/GT555
	Tape Mechanism Type	CS-21SC-900TP

### SPECIFICATIONS

#### Amplifier section

The following are measured at Mexican model:

AC 127 V, 60 Hz

Other models:

AC 120 V, 220 V, 240 V, 50/60 Hz

Front/Satellite Speaker

Power Output (rated):

200 W + 200 W (at 6 Ω, 1 kHz,  
1% THD)

Front Speaker

RMS output power (reference):  
345 W + 345 W (per channel at 8 Ω,  
1 kHz)

Satellite Speaker

RMS output power (reference):  
140 W + 140 W (per channel at 24 Ω,  
1 kHz)

Subwoofer

RMS output power (reference):  
200 W + 200 W (per channel at 6 Ω,  
100 Hz)

#### Inputs

PC (AUDIO IN) L/R

Voltage 700 mV, impedance 47 kilohms

MIC

Sensitivity 1 mV, impedance 10 kilohms

USB (USB port): Type A

#### Outputs

PHONES

Accepts headphones of 8 Ω or more

#### USB section

Supported bit rate

MP3 (MPEG 1 Audio Layer-3):  
32 kbps – 320 kbps, VBR  
WMA: 48 kbps – 192 kbps  
AAC: 48 kbps – 320 kbps

Sampling frequencies

MP3 (MPEG 1 Audio Layer-3):  
32 kHz/44.1 kHz/48 kHz  
WMA: 44.1 kHz  
AAC: 44.1 kHz

Transfer speed

Full-Speed

Supported USB device

Mass Storage Class

Maximum current

500 mA

#### Disc player section

System

Compact disc and digital audio system

Laser Diode Properties

Emission Duration: Continuous  
Laser Output\*: Less than 44.6 μW  
\* This output is the value measurement  
at a distance of 200 mm from the  
objective lens surface on the Optical  
Pick-up Block with 7 mm aperture.

Frequency response

20 Hz – 20 kHz

Signal-to-noise ratio

More than 90 dB  
Dynamic range  
More than 88 dB

#### Tape deck section (For African model only)

Recording system

4-track 2 channel, stereo

#### Tuner section

FM stereo, FM/AM superheterodyne tuner

#### FM tuner section

Tuning range

North American and Brazilian models:  
87.5 MHz – 108.0 MHz (100 kHz step)  
Other models:  
87.5 MHz – 108.0 MHz (50 kHz step)

Antenna

FM lead antenna

Antenna terminals

75 ohms unbalanced

Intermediate frequency

10.7 MHz

#### AM tuner section

Tuning range

Pan American and Oceanian models:  
530 kHz – 1,710 kHz (with 10 kHz tun-  
ing interval)  
531 kHz – 1,710 kHz (with 9 kHz tuning  
interval)

Other models:

530 kHz – 1,610 kHz (with 10 kHz tun-  
ing interval)  
531 kHz – 1,602 kHz (with 9 kHz tuning  
interval)

Antenna

AM loop antenna, external antenna  
terminal

Intermediate frequency

450 kHz

#### General

Power requirements

Oceanian model: AC 230 V – 240 V,  
50/60 Hz

Mexican model: AC 127 V, 60 Hz

Argentina model: AC 220 V, 50/60 Hz

Other models: AC 120 V, 220 V or  
230 V – 240 V, 50/60 Hz, Adjustable  
with voltage selector

Power consumption: 460 W

Dimensions (w/h/d) (excl. speakers)

(Approx.)

231 mm × 361 mm × 518 mm

Mass (excl. speakers) (Approx.)

African and Pan Asian models: 16.2 kg

Other models: 15.7 kg

Design and specifications are subject to  
change without notice.

- Abbreviation  
E4 : African model

## COMPACT DISC DECK RECEIVER

## NOTES ON CHIP COMPONENT REPLACEMENT

- Never reuse a disconnected chip component.
- Notice that the minus side of a tantalum capacitor may be damaged by heat.

## FLEXIBLE CIRCUIT BOARD REPAIRING

- Keep the temperature of soldering iron around 270 °C during repairing.
- Do not touch the soldering iron on the same conductor of the circuit board (within 3 times).
- Be careful not to apply force on the conductor when soldering or unsoldering.

## SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety check before releasing the set to the customer:


Check the antenna terminals, metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC leakage.

Check leakage as described below.

## LEAKAGE TEST

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5 mA (500 microamperes.). Leakage current can be measured by any one of three methods.

1. A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75 V, so analog meters must have an accurate low-voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. Nearly all battery operated digital multimeters that have a 2 V AC range are suitable. (See Fig. A)



**Fig. A. Using an AC voltmeter to check AC leakage.**

## CAUTION

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

CLASS 1 LASER PRODUCT  
LUOKAN 1 LASERLAITE  
KLASS 1 LASERAPPARAT

This appliance is classified as a CLASS 1 LASER product. This marking is located on the rear exterior.

## SAFETY-RELATED COMPONENT WARNING!

COMPONENTS IDENTIFIED BY MARK ▲ OR DOTTED LINE WITH MARK ▲ ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

## TABLE OF CONTENTS

1. SERVICING NOTES .....	3
2. DISASSEMBLY	
2-1. Disassembly Flow .....	5
2-2. Case (Side-L/R) .....	6
2-3. Top Case .....	6
2-4. Tape Mechanism Deck (For African Model only) .....	7
2-5. Front Panel Block, HUB Board, DMB19 Board .....	7
2-6. DC Fan (M101) .....	8
2-7. Back Panel, SUBTRANS Board .....	8
2-8. MAIN Board .....	9
2-9. DC Fan (M101), PT SHIELD Board, POWER AMP Board Section .....	9
2-10. POWER AMP Board, SUBWOOFER Board .....	10
2-11. Chassis Section .....	10
2-12. CD Mechanism Block (CDM88BL-DVBU101) .....	11
2-13. Optical Pick-up Block (KHM-313CAB) .....	11
2-14. Belt (DLM3A) .....	12
3. TEST MODE .....	13
4. MECHANICAL ADJUSTMENTS .....	15
5. ELECTRICAL ADJUSTMENTS .....	16
6. DIAGRAMS	
6-1. Block Diagram - RF SERVO, USB Section - .....	17
6-2. Block Diagram - MAIN Section - .....	18
6-3. Block Diagram - AMP Section - .....	19
6-4. Block Diagram - DISPLAY, POWER SUPPLY Section - .....	20
6-5. Printed Wiring Board - DISPLAY Board - .....	22
6-6. Schematic Diagram - DISPLAY Board - .....	23
6-7. Printed Wiring Board - DMB19 Board - .....	24
6-8. Schematic Diagram - DMB19 Board (1/3) - .....	25
6-9. Schematic Diagram - DMB19 Board (2/3) - .....	26
6-10. Schematic Diagram - DMB19 Board (3/3) - .....	27
6-11. Printed Wiring Board - POWER AMP Board - .....	28
6-12. Schematic Diagram - POWER AMP Board - .....	29
6-13. Printed Wiring Board - MAIN Board - .....	30
6-14. Schematic Diagram - MAIN Board (1/3) - .....	31
6-15. Schematic Diagram - MAIN Board (2/3) - .....	32
6-16. Schematic Diagram - MAIN Board (3/3) - .....	33
6-17. Printed Wiring Board - MIC, VOL and USB Board - ....	34
6-18. Schematic Diagram - MIC, VOL and USB Boards - ....	35
6-19. Printed Wiring Board - TC Board - .....	36
6-20. Schematic Diagram - TC Board - .....	36
6-21. Printed Wiring Board - TRANS and SUBTRANS Board - .....	37
6-22. Schematic Diagram - TRANS and SUBTRANS Boards - .....	38
6-23. Printed Wiring Board - SUBWOOFER Board - .....	39
6-24. Schematic Diagram - SUBWOOFER Board - .....	40
6-25. Printed Wiring Board - HUB Board - .....	41
6-26. Schematic Diagram - HUB Board - .....	42
7. EXPLODED VIEWS	
7-1. Case Section .....	53
7-2. Top Panel Section .....	54
7-3. Loading Panel Section, HUB Board Section, DMB19 Board Section .....	55
7-4. DISPLAY Board Section .....	56
7-5. Front Panel Section .....	57
7-6. Back Panel Section .....	58
7-7. MAIN Board Section .....	59
7-8. Chassis Section .....	60
7-9. CD Mechanism Section (CDM88BL-DVBU101) .....	61
8. ELECTRICAL PARTS LIST .....	62

## SECTION 1 SERVICING NOTES

### NOTES ON HANDLING THE OPTICAL PICK-UP BLOCK OR BASE UNIT

The laser diode in the optical pick-up block may suffer electrostatic break-down because of the potential difference generated by the charged electrostatic load, etc. on clothing and the human body. During repair, pay attention to electrostatic break-down and also use the procedure in the printed matter which is included in the repair parts.

The flexible board is easily damaged and should be handled with care.

### NOTES ON LASER DIODE EMISSION CHECK

The laser beam on this model is concentrated so as to be focused on the disc reflective surface by the objective lens in the optical pickup block. Therefore, when checking the laser diode emission, observe from more than 30 cm away from the objective lens.

### UNLEADED SOLDER

Boards requiring use of unleaded solder are printed with the lead-free mark (LF) indicating the solder contains no lead.

(Caution: Some printed circuit boards may not come printed with the lead free mark due to their particular size)

#### : LEAD FREE MARK

Unleaded solder has the following characteristics.

- Unleaded solder melts at a temperature about 40 °C higher than ordinary solder.  
Ordinary soldering irons can be used but the iron tip has to be applied to the solder joint for a slightly longer time.  
Soldering irons using a temperature regulator should be set to about 350 °C.  
**Caution:** The printed pattern (copper foil) may peel away if the heated tip is applied for too long, so be careful!
- Strong viscosity  
Unleaded solder is more viscous (sticky, less prone to flow) than ordinary solder so use caution not to let solder bridges occur such as on IC pins, etc.
- Usable with ordinary solder  
It is best to use only unleaded solder but unleaded solder may also be added to ordinary solder.

### NOTE OF REPLACING THE IC102 ON THE DMB19 BOARD

IC102 on the DMB19 board cannot exchange with single. When this part is damaged, exchange the entire mounted board.

### RELEASING THE DISC TRAY LOCK


The disc tray lock function for the antitheft of an demonstration disc in the store is equipped.

#### Releasing Procedure:

1. Press [I/待機] STANDBY] button to turn the power on.
2. Press the [CD] button to select CD function.
3. While pressing the [■] button, press the [**▲ OPEN/CLOSE**] button for more 5 seconds).
4. The message “UNLOCKED” is displayed and the disc tray is unlocked.

**Note:** When “LOCKED” is displayed, the slot lock is not released by turning power on/off with the [I/待機] STANDBY] button.

### MODEL IDENTIFICATION – Back Panel –




Model	Part No.
HCD-GTR88: E2, E51	4-164-385-0□
HCD-GTR88: AR	4-164-385-1□
HCD-GTR88: MX	4-164-385-2□
HCD-GTR88: E4	4-164-385-4□
HCD-GTR88: AUS	4-164-385-5□

#### • Abbreviation

AR	: Argentina model
AUS	: Australian model
E2	: 120V AC area in E model
E4	: African model
E51	: Chilean and Peruvian models
MX	: Mexican model

## HOW TO OPEN THE TRAY WHEN POWER SWITCH TURN OFF


- Step: 1) Work after removing the case (side-R and side-L) referring to “2.2. CASE (SIDE-L/R)” on disassembly (page 6).  
 2) Work after removing the top case referring to “2-3. TOP CASE” on disassembly (page 6).



## HOW TO DISTINGUISH TAPE MECHANISM DECK

Two kinds of tape mechanism decks installed by this set exist.

Please do the repair exchange after confirming which tape mechanism deck set of the repair according to how to distinguish the figure below.




Tape Deck Name	Tape Deck Part No.	Belt Part No.
CS-21SC-900TP	1-797-575-11	2-688-621-01 BELT (R/F)
		2-688-622-01 BELT (MAIN)

## SECTION 2 DISASSEMBLY


- This set can be disassembled in the order shown below.

### 2-1. DISASSEMBLY FLOW




**Note:** Follow the disassembly procedure in the numerical order given.


## 2-2. CASE (SIDE-L/R)




## 2-3. TOP CASE




## 2-4. TAPE MECHANISM DECK (FOR AFRICAN MODEL ONLY)




## 2-5. FRONT PANEL BLOCK, HUB BOARD, DMB19 BOARD




## 2-6. DC FAN (M101)




## 2-7. BACK PANEL, SUBTRANS BOARD




## 2-8. MAIN BOARD




## 2-9. DC FAN (M101), PT SHIELD BOARD, POWER AMP BOARD SECTION




## 2-10. POWER AMP BOARD, SUBWOOFER BOARD




## 2-11. CHASSIS SECTION




## 2-12. CD MECHANISM BLOCK (CDM88BL-DVBU101)



## 2-13. OPTICAL PICK-UP BLOCK (KHM-313CAB)



2-14. BELT (DLM3A)



## SECTION 3

### TEST MODE

#### PANEL TEST MODE

This mode is used to check the fluorescent indicator tube, LEDs, keys, [MASTER VOLUME] jog, [OPERATION DIAL] jog, model, destination and software version.

##### Procedure:

1. Press [■], button, [METER MODE] button and [DISC SKIP/EX-CHANGE] button simultaneously.
2. All LEDs and segments in fluorescent indicator tube are lighted up.
3. When you want to enter to the software version display mode, press [DISC 1] button. The model information appears on the fluorescent indicator tube.
  - “GVX 7S” is shown for MHC-GTR88.
4. Press [DISC 1] button again to view the destination information.
5. During the destination information display, press [DISC 1] button. Each time [DISC 1] button is pressed, the fluorescent indicator tube shows the version of each category software in the following sequence: SC, MTK (DMB Board firmware version), GC, SYS, CD, CDMA, CDMB, ST, TC TA, TM, MTR (METER) and return back to model information display.
6. When [DISC 3] button is pressed while the version numbers are being displayed except model and destination, the date of the software creation appears. When [DISC 3] button is pressed again, the display returns to the software version display. When [DISC 1] button is pressed while the date of the software creation is being displayed, the date of the software creation is displayed in the same order of software version display.
7. Press [DISC 2] button, the key check mode is activated.
8. In the key check mode, the fluorescent indicator tube displays “K0 V0”. Each time a button is pressed, “K” value increases. However, once a button has been pressed, it is no longer taken into account. “V” value increases in the manner of 0, 1, 2, 3 ... if [MASTER VOLUME] knob is turned clockwise, or it decreases in the manner of 0, 9, 8, 7 ... if [MASTER VOLUME] knob is turned counterclockwise.
9. When [DISC SKIP/EX-CHANGE] button is pressed after all LEDs and segments in fluorescent indicator tube light up, alternate segments in fluorescent indicator tube and LEDs would light up. If you press [DISC SKIP/EX-CHANGE] button again, another half of alternate segments in fluorescent indicator tube and LEDs would light up. Pressing [DISC SKIP/EX-CHANGE] button again would cause all segments in fluorescent indicator tube and LEDs light up.
10. To release from this mode, press three buttons in the same manner as step 1, or disconnect the power cord.

#### COMMON TEST MODE

This mode is used to check operations of the Amplifier section.

##### To enter Common Test Mode

##### Procedure:

1. Press [■], button, [METER MODE] button and [OPEN/CLOSE] button simultaneously.
2. The CD ring indicators flash on the fluorescent indicator tube. The function is changed to AUDIO and the volume is changed to VOLUME MIN.

##### Check of Amplifier

##### Procedure:

1. Press [EQ BAND/SURROUND] button repeatedly until a message “GEQ MAX” appears on the fluorescent indicator tube. GEQ increases to its maximum.

2. Press [EQ BAND/SURROUND] button repeatedly until a message “GEQ MIN” appears on the fluorescent indicator tube. GEQ decreases to its minimum.
3. Press [EQ BAND/SURROUND] button repeatedly until a message “GEQ FLAT” appears on the fluorescent indicator tube. GEQ is set to flat.
4. When the [MASTER VOLUME] knob is turned clockwise even slightly, the sound volume increases to its maximum and a message “VOLUME MAX” appears on the fluorescent indicator tube.
5. When the [MASTER VOLUME] knob is turned counterclockwise even slightly, the sound volume decreases to its minimum and a message “VOLUME MIN” appears on the fluorescent indicator tube.

#### To release from Common Test mode

1. To release from this mode, press [I/O STANDBY] button.
2. The cold reset is enforced at the same time.

#### COLD RESET

The cold reset clears all data including preset data stored in the EEPROM to initial conditions. Execute this mode when returning the set to the customer.

##### Procedure:

1. Press [I/O STANDBY] button to turn on the system.
2. Press [■] button, [ENTER] button, and [I/O STANDBY] button simultaneously.
3. “COLD RESET” appears on the fluorescent indicator tube. After that, the fluorescent indicator tube becomes blank for a while, and the system is reset.

#### VACS ON/OFF

This mode is used to switch ON and OFF the VACS (Variable Attenuation Control System).

##### Procedure:

1. Press [I/O STANDBY] to turn on the system.
2. Press [■] button, [RETURN], and [DISPLAY] button simultaneously. The message “VACS OFF” or “VACS ON” appears on the fluorescent indicator tube.

#### TUNER STEP CHANGE

The step interval of AM channels can be toggled between 9 kHz and 10 kHz.

##### Procedure:

1. Press [I/O STANDBY] button to turn on the system.
2. Press [TUNER/BAND] button repeatedly to select the “AM”.
3. Press [I/O STANDBY] button to turn off the system.
4. Press [ENTER] button and [I/O STANDBY] button simultaneously. The system turns on automatically. The message “AM 9K STEP” or “AM 10K STEP” appears on the fluorescent indicator tube and thus the channel step is changed.

#### CD SHIP MODE (WITH MEMORY CLEAR)

This mode moves the optical pick-up to the position durable to vibration and clears all data including preset data stored in the EEPROM to initial conditions during the next AC-In. Use this mode when returning the set to the customer after repair.

##### Procedure:

1. Press [I/O STANDBY] button to turn on the system.
2. Select CD function.
3. Press [■] button, [OPEN/CLOSE] button and [I/O STANDBY] button simultaneously. The system turns off automatically.
4. After the “STANDBY” blinking display finishes, a message “MECHA LOCK” is displayed on the fluorescent indicator tube and the CD ship mode is set.

## CD SHIP MODE (WITHOUT MEMORY CLEAR)

This mode moves the optical pick-up to the position durable to vibration. Use this mode when returning the set to the customer after repair.

### Procedure:

1. Press [I/∅ STANDBY] button to turn on the system.
2. Select CD function.
3. Press [DISC SKIP/EX-CHANGE] button and [I/∅ STANDBY] button simultaneously. The system turns off automatically.
4. After the “STANDBY” blinking display finishes, a message “MECHA LOCK” is displayed on the fluorescent indicator tube and the CD ship mode is set.

## CD TRAY LOCK MODE

This mode let you lock the disc tray. When this mode is activated, the disc tray will not open when [ $\triangle$  OPEN/CLOSE] button or [DISC SKIP/EX-CHANGE] button is pressed. The message “LOCKED” will be displayed on the fluorescent indicator tube. This mode only applied when there is disc(s) on the tray.

### Procedure:

1. Press [I/∅ STANDBY] button to turn on the system.
2. Select CD function.
3. Press [■] button and [ $\triangle$  OPEN/CLOSE] button simultaneously and hold down until “LOCKED” or “UNLOCKED” displayed on the fluorescent indicator tube (around 5 seconds).

## FACTORY PRESET

This mode is used to load all the factory use preset frequencies into FM 1-FM 20 and AM 1-AM 10. Originally, frequency of FM 1-FM 20 and AM 1-AM10 are set to the minimum frequency.

### Procedure:

1. Press [I/∅ STANDBY] button to turn on the system.
2. Press [EQ BAND/SURROUND], [■] button, and [DISC 1] button simultaneously and the message “FACTORY” appears on the fluorescent indicator tube. The function is changed to TUNER automatically.

## VACS DISPLAY

This mode is used to check the VACS level.

### Procedure:

1. Press [I/∅ STANDBY] button to turn on the system.
2. Press [ERASE], [■] button and [ENTER] button simultaneously.
3. The fluorescent indicator tube displays “V0AP0”.  
“V” represents Conventional VACS (Triggered by signal level)  
“AP” represents AP VACS (Abuse Protection Variable Attenuation Control System)
  - To release from VACS display mode  
To release from this mode, do the step (2) again.

## METER SWITCH TOUCH COUNT DISPLAY

This mode is used to display the total count of meter pointer touch initial switch and max switch.

### Procedure:

1. Press [I/∅ STANDBY] button to turn on the system.
2. Press [■] button, [ENTER] button and [DISPLAY] button simultaneously.
3. The fluorescent indicator tube displays “IxxxxxMyyyyy”.  
“I” represents the Initial Switch touch.  
“xxxxx” represents the total count of Initial Switch touch.  
(Maximum Value of “xxxxx” = 65535)  
“M” represents the Max Switch touch.  
“yyyyy” represents the total count of Max Switch touch.  
(Maximum Value of “yyyyy” = 65535)
  - To release from Meter Switch Touch Count Display Mode.  
To release from this mode, do the step (2) again.  
The fluorescent indicator tube displays “MODE OUT”.

## METER TEST MODE

This mode is used to check the meter device.

### Procedure:

1. Press [I/∅ STANDBY] button to turn on the system.
2. Press [■] button, [ENTER] button and [METER MODE] button simultaneously.
3. Meter Backlight LEDs, Meter Pointer LEDs, Power Illuminator LEDs and fluorescent indicator tube are lighted up.
4. When you want to perform count total step from Initial Switch to Max Switch operation mode, press [ $\gg\gg\gg$ /TUNING +] button. The meter pointer will move from Initial Switch to Max Switch and finally move back to the middle position. The total step count information appears on the fluorescent indicator tube. “xxx STP yy” is shown.

“xxx” represents the total step.

(Value of “xxx” should between 430 steps to 470 steps)

“yy” represents the status of total step count.

(If total step between 430 steps to 470 steps, “yy” is OK, Else “yy” is NG)

5. When you want to perform count total step from Max Switch to Initial Switch operation mode, press [ $\ll\ll\ll$ /TUNING -] button. The meter pointer will move from Max Switch to Initial Switch and finally move back to the middle position. The total step count information appears on the fluorescent indicator tube. “xxx STP yy” is shown.

“xxx” represents the total step.

(Value of “xxx” should between 430 steps to 470 steps)

“yy” represents the status of total step count.

(If total step between 430 steps to 470 steps, “yy” is OK, else “yy” is NG)

- To release from Meter Test Mode.  
To release from this mode, do the step (2) again.  
The fluorescent indicator tube displays “TST MODE OUT”.

## CDM AGING MODE

This mode is used to display the total count of all disc playing.

### Procedure:

1. Press [I/∅ STANDBY] button to turn on the system.
2. Select CD function and All DISC play mode.
3. Put discs on all trays and close the tray.
4. Press [GROOVE] button, [■] button and [RETURN] button simultaneously.
5. The fluorescent indicator tube displays Aging Display “AG xxxx/yyyy”.  
“xxxx” represents the error counter  
(Maximum Value of “xxxx” = 9999)  
“yyyy” represents the cycle counter  
(Maximum Value of “yyyy” = 9999)
6. Press [ $\ll\ll\ll$ /TUNING -] or [ $\gg\gg\gg$ /TUNING +] to search for Aging History Error Display  
The fluorescent indicator tube displays “Mx E1E2E3E4”.  
x: error history number  
E1: Loading sequence JCP high  
E2: Loading sequence JCP low  
E3: Loading operation JCP  
E4: Cam position operation JCP
7. Press [RETURN] to Aging Display
  - To release from CDM Aging Mode.  
To release from this mode, press [I/∅ STANDBY] button or perform COLD RESET operation.

## SECTION 4

### MECHANICAL ADJUSTMENTS

(For African model only)

#### **PRECAUTION**

1. Clean the following parts with a denatured-alcohol-moistened swab :
 

record/playback head	pinch roller
erase head rubber	belts
capstan	idle
2. Demagnetize the record/playback head with a head demagnetizer. (Do not bring the head magnetizer close to the erase head.)
3. Do not use a magnetized screwdriver for the adjustments.
4. After the adjustments, apply suitable locking compound to the parts adjusted.
5. The adjustments should be performed with the rated power supply voltage unless otherwise noted.

- Torque Measurement

Mode	Torque Meter	Meter Reading
FWD	CQ-102AS	2.0 – 8.0 mN • m (20 to 80 g • cm) (0.28 – 1.12 oz • inch)
FWD Back Tension	CQ-102C	0.15 – 0.6 mN • m (1.5 to 6 g • cm) (0.021 – 0.083 oz • inch)
FF	CQ-201AS	5 – 17.7 mN • m (50 to 177 g • cm) (0.7 – 2.48 oz • inch)
REV	CQ-201B	5 – 17.7 mN • m (50 to 177 g • cm) (0.7 – 2.48 oz • inch)


- Tape Tension Measurement

Mode	Torque Meter	Meter Reading
FWD	CQ-403A	more than 80 g (more than 2.82 oz)

## SECTION 5 ELECTRICAL ADJUSTMENTS

### TUNER SECTION

#### FM TUNE LEVEL CHECK



##### Procedure:

1. Turn the power on.
2. Input the following signal from signal generator to FM antenna input directly.

\* Carrier frequency : A = 87.5 MHz, B = 98 MHz, C = 108 MHz  
 Deviation : 75 kHz  
 Modulation : 1 kHz  
 ANT input : 35 dBu (EMF)

**Note:** Use 75 ohm coaxial cable to connect signal generator and the set.  
 You cannot use video cable for checking.  
 Use signal generator whose output impedance is 75 ohm.

3. Set to FM tuner function and tune A, B and C signals.
4. Confirm "TUNED" is lit on the display for A, B and C signals.

When mark of "TUNED" means "The selected station signal is received in good condition."

### DECK SECTION

$0\text{dB} = 0.775\text{V}$

(For African model only)

1. Demagnetize the record/playback head with a head demagnetizer.
2. Do not use a magnetized screwdriver for the adjustments.


#### TEST TAPE

Tape	Signal	Used for
P-4-A063	6.3 kHz, -10 dB	Azimuth Adjustment


#### RECORD/PLAYBACK HEAD AZIMUTH ADJUSTMENT

##### Procedure:



1. Mode: Playback



2. Turn the adjustment screw and check output peaks. If the peaks do not match for L-CH and R-CH, turn the adjustment screw so that outputs match within 1dB of peak.




3. Mode: Playback




4. After the adjustments, apply suitable locking compound to the parts adjusted.

**Adjustment Location:** Record/Playback/Erase Head




SECTION 6  
DIAGRAMS


## 6-1. BLOCK DIAGRAM - RF SERVO, USB Section -




## 6-2. BLOCK DIAGRAM - MAIN Section -



## 6-3. BLOCK DIAGRAM - AMP Section -



## 6-4. BLOCK DIAGRAM - DISPLAY, POWER SUPPLY Section -



**THIS NOTE IS COMMON FOR PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS.**

(In addition to this, the necessary note is printed in each block.)

**For Printed Wiring Boards.**

Note:  
 • : Parts extraced from the component side.

• : Parts extraced from the conductor side.

• : Internal component.

• : Pattern from the side which enables seeing.

(The other layers' patterns are not indicated.)

Caution:  
 Pattern face side: Parts on the pattern face side seen

(Conductor Side) from the pattern face are indicated.

Parts face side: Parts on the parts face side seen from

(Component Side) the parts face are indicated.

Caution:  
 Pattern face side: Parts on the pattern face side seen

(SIDE B) from the pattern face are indicated.


Parts face side: Parts on the parts face side seen from

(SIDE A) the parts face are indicated.

• DMB19 board is multi-layer printed board.

However, the patterns of intermediate layers have not been included in diagrams.

• Indication of transistor.



These are omitted.



These are omitted.

Abbreviation

AR : Argentine model

AUS : Australian model


E2 : 120V AC area in E model

E4 : African model

E51 : Chilean and Peruvian models

MX : Mexican model

• Circuit Boards Location



**For Schematic Diagrams.**

Note:

• All capacitors are in  $\mu\text{F}$  unless otherwise noted (p:  $\mu\text{F}$ ) 50  $\text{WV}$  or less are not indicated except for electrolytes and tantalums.

• All resistors are in  $\Omega$  and 1/4  $\text{W}$  or less unless otherwise specified.

• : Internal component.

• : Nonflammable resistor.

• : Fusible resistor.

• : Panel designation.

Note: The components identified by mark or dotted line with mark are critical for safety. Replace only with part number specified.

• : B+ Line.

• : B- Line.

• Voltages and waveforms are dc with respect to ground under no-signal (detuned) conditions.

- TC Board -

no mark : TAPE PLAY

( ) : TAPE REC

- Other Boards -

no mark : TUNER (FM/AM)

( ) : CD PLAY

<> : TAPE PLAY

[ ] : TAPE REC

<> : USB

[ ] : PC

\* : Impossible to measure

• Voltages are taken with VOM (Input impedance  $10 \text{ M}\Omega$ ).  
 Waveforms are taken with a oscilloscope.  
 Voltage variations may be noted due to normal production tolerances.

• Voltages variations may be noted due to normal production tolerances.  
 Circled numbers refer to waveforms.

• Signal path.

: AUDIO

: TUNER (FM/AM)

: TAPE PLAY

: TAPE REC

: MIC

: CD PLAY

: DIGITAL

: USB

• Abbreviations

AR : Argentine model

AUS : Australian model


E2 : 120V AC area in E model


E4 : African model

E51 : Chilean and Peruvian models

MX : Mexican model


6-5. PRINTED WIRING BOARD - DISPLAY Board - • See page 21 for Circuit Boards Location. • : Uses unleaded solder.






1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----


## [DMB19 BOARD] (COMPONENT SIDE)




## [DMB19 BOARD] (CONDUCTOR SIDE)




Note: When IC102 cannot exchange with single. When this part is damaged, exchange the entire mounted board.




Note: When IC102 cannot exchange with single. When this part is damaged, exchange the entire mounted board.



6-10. SCHEMATIC DIAGRAM - DMB19 Board (3/3) - • See page 43 for Waveforms. • See page 44 for IC Block Diagrams. • See page 48 for IC Pin Function Description.




[POWER AMP BOARD]



28

HCD-G | R<sup>88</sup>

6-12. SCHEMATIC DIAGRAM - POWER AMP Board • See page 43 for Waveforms. • See page 44 for IC Block Diagrams. • See page 48 for IC Pin Function Description.



卷之三

[MAINBOARD]

**E**  
SUBTRANS BOARD  
NO1203  
(Page 37)

**D** POWER AMP BOARD  
CN1300  
(Page 28)


FM750  
CONVEX

BN  
COAWA  
FM750


EN/TELA  
COVADON


FM-7501  
COVINA

FM750  
CONVIA





6-14. SCHEMATIC DIAGRAM - MAIN Board (1/3) - • See page 43 for Waveforms. • See page 44 for IC Block Diagrams. • See page 48 for IC Pin Function Description.






6-16. SCHEMATIC DIAGRAM - MAIN Board (3/3) - • See page 43 for Waveforms. • See page 44 for IC Block Diagrams. • See page 48 for IC Pin Function Description.






6-18. SCHEMATIC DIAGRAM - MIC, VOL and USB Board - • See page 43 for Waveforms. • See page 44 for IC Block Diagrams. • See page 48 for IC Pin Function Description.




## 6-19. PRINTED WIRING BOARD - TC Board - (For African model only)


• See page 21 for Circuit Boards Location. • **IF** : Uses unlead solder.



## 6-20. SCHEMATIC DIAGRAM - TC Board - (For African model only)




[TRANS BOARD]




POWER AMP BC  
NO1300  
(Page 28)

[SUBTRANS BOARD]




**E**  
MAIN BOARD  
CN691  
(Page 30)




6-23. PRINTED WIRING BOARD - SUBWOOFER Board - • See page 21 for Circuit Boards Location. • **UF** : Uses unleaded solder.

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----


## [SUBWOOFER BOARD]





### [HUB BOARD] (COMPONENT SIDE)


**M**  
USBBOARD  
NO1002  
(Page 34)




**O**  
MANBOARD  
CN150  
(Page 30)

**Q**  
DWB19BOARD  
CN1105  
(Page 24)

### [HUB BOARD] (CONDUCTOR SIDE)




**12**  
[12]  
1-881-132




- Waveforms


— DMB19 BOARD —



— MAIN BOARD —




— HUB BOARD —




# HCD-GTR88

- IC Block Diagrams


IC1101 PT6324-Q (DISPLAY Board)




IC107 TK11133CSCL-G (DMB19 Board (1/3))




IC111 MM1661JHBE (DMB19 Board (1/3))




## IC201 FAN8036L (DMB19 Board (2/3))




## IC4601 PCM1808PWR (DMB19 Board (3/3))



## IC4602 CS4335-KSZR (DMB19 Board (3/3))



## IC1500 NJM2903V (TE2) (HUB Board)



## IC251 NJM4558V-TE2 (MAIN Board (2/3))


IC252 NJM4558V-TE2 (MAIN Board (2/3))

IC253 NJM4558V-TE2 (MAIN Board (2/3))

IC254 NJM4558V-TE2 (MAIN Board (2/3))


IC255 NJM4558V-TE2 (MAIN Board (2/3))

IC700 NJM4558V-TE2 (MIC Board)




## IC065 SI-8008TM-TLS (MAIN Board (3/3))


IC075 SI-8008TM-TLS (MAIN Board (3/3))



IC400 R2A15216FP (MAIN Board (2/3))



IC800 STK433-130-E (SUBWOOFER Board)



- IC Pin Function Description

DMB19 BOARD (1/3) IC101 CXD9968R (LE) (RF AMP, SERVO DSP, AUDIO PROCESSOR)

Pin No.	Pin Name	I/O	Description
1	RF_A	I	RF main beam (C) input from the optical pick-up block
2	RF_B	I	RF main beam (B) input from the optical pick-up block
3	RF_C	I	RF main beam (A) input from the optical pick-up block
4	RF_D	I	RF main beam (D) input from the optical pick-up block
5	RF_E	I	RF sub beam (F) input from the optical pick-up block
6	RF_F	I	RF sub beam (E) input from the optical pick-up block
7	AVDD18_2	-	Power supply terminal (+1.8V)
8	AVDD33_1	-	Power supply terminal (+3.3V)
9	XTALI	I	System clock input terminal (27 MHz)
10	XTALO	O	System clock output terminal (27 MHz)
11	AGND33	-	Ground terminal
12	V2O	O	Reference voltage (+2V) output to the optical pick-up block
13	V14/VREFO	O	Reference voltage (+1.4V) output terminal
14	REXT	I	Current reference input terminal Fixed at "L" in this set
15, 16	MDI1, MDI2	I	Laser power monitor input from the optical pick-up block
17, 18	LDO1, LDO2	O	Laser diode drive signal output to the optical pick-up block
19	AVDD33_2	-	Power supply terminal (+3.3V)
20	DMO	O	Spindle motor control signal output to the motor driver
21	FMO	O	Sled motor control signal output to the motor driver
22	MUTE4	O	Muting signal output to the coil/motor driver (for spindle motor)
23	MSW	O	CD/DVD selection signal output terminal "L": CD, "H": DVD
24	TRO	O	Tracking coil control signal output to the coil driver
25	FOO	O	Focus coil control signal output to the coil driver
26	EEWP	-	Not used
27, 28	USB_DP, USB_DM	I/O	Two-way audio serial data with the USB controller
29	VDD33_USB	-	Power supply terminal (+3.3V)
30	VSS33_USB	-	Ground terminal
31	PAD_VRT	I/O	USB generating reference current terminal
32	VDD18_USB	-	Power supply terminal (+1.8V)
33	SCL	O	Serial clock signal output to the EEPROM (GTZ4i)
34	SDA	I/O	Two-way serial data with the EEPROM (GTZ4i)
35	IFSDI	I	Serial data input from the system controller
36	FS_CS#	O	Chip select signal output to the flash ROM
37	SF_DO	O	Serial data output to the flash ROM
38	SF_DI	I	Serial data input from the flash ROM
39	SF_CK	O	Serial clock signal output to the flash ROM
40	IFSCK	O	Serial data transfer clock signal output to the system controller
41	IFSOD	O	Serial data output to the system controller
42	ICE	I	ICE mode enable setting terminal Not used
43	PRST#	I	Reset signal input from the system controller "L": reset
44	IR	I	IR control signal input terminal Not used
45 to 49	RD0 to RD4	I/O	Two-way data bus with the SD-RAM
50	DVDD33	-	Power supply terminal (+3.3V)
51 to 53	RD5 to RD7	I/O	Two-way data bus with the SD-RAM
54	DVDD18	-	Power supply terminal (+1.8V)
55	DQMO	O	Data mask signal output to the SD-RAM
56 to 59	RD15 to RD 12	I/O	Two-way data bus with the SD-RAM
60	DVSS33	-	Ground terminal
61 to 64	RD11 to RD8	I/O	Two-way data bus with the SD-RAM
65	DQM1	O	Data mask signal output to the SD-RAM
66	RCLK	O	Clock signal output to the SD-RAM
67	RA11	O	Address signal output to the SD-RAM
68	DVDD33	-	Power supply terminal (+3.3V)
69 to 74	RA9 to RA4	O	Address signal output to the SD-RAM
75	RWE#	O	Write enable signal output to the SD-RAM
76	CAS#	O	Column address strobe signal output to the SD-RAM
77	RAS#	O	Row address strobe signal output to the SD-RAM

Pin No.	Pin Name	I/O	Description
78	BA0	O	Bank address signal output to the SD-RAM
79	DVSS18	-	Ground terminal
80	BA1	O	Bank address signal output to the SD-RAM
81 to 83	RA10, RA0, RA1	O	Address signal output to the SD-RAM
84	DVDD33	-	Power supply terminal (+3.3V)
85, 86	RA2, RA3	O	Address signal output to the SD-RAM
87	IFBSY	I	Communication initialization request signal input from the system controller
88	IFCS#	O	Communication initialization request acknowledge signal output to the system controller
89	RX	-	Not used
90	DVDD18	-	Power supply terminal (+1.8V)
91	TX	-	Not used
92	XMAMUTE	-	Not used
93	SPDIF	O	SPDIF signal output terminal Not used
94	GPIO	I	Thermal shut down signal input from the coil/motor driver
95	DACVDDC	-	Power supply terminal (+3.3V)
96	VREF	I	Band gap reference voltage terminal
97	FS	I	Full scale adjustment terminal
98	DACVSSC	-	Ground terminal
99	CVBS	O	Composite video signal output terminal Not used
100, 101	DACVDBB, DACVDDA	-	Power supply terminal (+3.3V)
102	SY/Y/G	O	Component video (Y) signal output terminal Not used
103	SC/CB/B	O	Component video (Pb/Cb) signal output terminal Not used
104	CR/R	O	Component video (Pr/Cr) signal output terminal Not used
105	AADVSS	-	Ground terminal
106	GPIO19	I	Audio data input from the A/D converter (for USB)
107	MUTE123	-	Not used
108	LIMITSW	-	Not used
109, 110	AADVDD, APDVDD	-	Power supply terminal (+3.3V)
111	APLLCAP	I	External capacitor connecting terminal
112, 113	ADACVSS2, ADACVSS1	-	Ground terminal
114	GPIO	O	Master clock signal output to the A/D converter and D/A converter
115	GPIO	O	Bit clock signal output to the A/D converter and D/A converter
116	GPIO	O	Muting signal output to the coil/motor driver (for focus/tracking coil and sled motor)
117	AVCM	-	Audio D/A converter reference voltage terminal
118	GPIO	I	Limit detection switch input terminal
119	GPIO	O	L/R sampling clock signal output to the A/D converter and D/A converter
120	GPIO	O	Audio data output to the D/A converter
121, 122	ADACVDD1, ADACVDD2	-	Power supply terminal (+3.3V)
123	AVDD18_1	-	Power supply terminal (+1.8V)
124	AGND18	-	Ground terminal
125, 126	RF_IP, OPOUT	I	AC coupled RF signal input from the optical pick-up block
127	IOPMON/OPINP	I	Power monitor terminal
128	SPFG/OPINN	I	Spindle motor hall sensor input from the motor driver

## HUB BOARD IC1501 USB2512A-AEZG (USB CONTROLLER)

Pin No.	Pin Name	I/O	Description
1, 2	USBDN1_DM, USBDN1_DP	I	Audio serial data input from the USB A connector
3, 4	USBDN2_DM, USBDN2_DP	I/O	Two-way audio serial data with the USB B connector
5	VDDA33	-	Power supply terminal (+3.3V)
6 to 9	NC	-	Not used
10	VDDA33	-	Power supply terminal (+3.3V)
11	TEST	-	Not used
12	PRTPWR1	O	Not used
13	OCS1_N	I	Over current sense signal input from the USB interface
14	VDD18	-	Power supply terminal (+1.8V)
15	VDD33CR	-	Power supply terminal (+3.3V)
16	PRTPWR2	O	Not used
17	OCS2_N	I	Over current sense signal input terminal
18 to 21	NC	-	Not used
22	SDA/SMBDATA/ NON/REM1	-	Not used
23	VDD33	-	Power supply terminal (+3.3V)
24	SCL/SMBCLK/ CFG_SEL0	-	Not used
25	HS_IND/CFG_SEL1	-	Not used
26	RESET_N	I	Reset signal input from the system controller “L”: reset
27	VBUS_DET	I	VBUS voltage detect signal input from the system controller
28	SUSP_IND/LOCAL_ PWR/NON_PEM0	-	Not used
29	VDDA33	-	Power supply terminal (+3.3V)
30, 31	USBUP_DM, USBUP_DP	I/O	Two-way audio serial data with the audio processor
32	XTAL2	O	System clock (24 MHz) output terminal
33	XTAL1/CLKIN	I	System clock (24 MHz) input terminal
34	VDD18PLL	-	Power supply terminal (+1.8V)
35	RBIAS	-	Not used
36	VDD33PLL	-	Power supply terminal (+3.3V)

## MAIN BOARD (1/3) IC401 R5F3640DDFA (SYSTEM CONTROLLER)

Pin No.	Pin Name	I/O	Description
1	FL-DRIVER-CLK	O	Serial data clock signal to FL Driver, PT6324
2	FL-DRIVER-DATA	O	Serial data output signal to FL Driver, PT6324
3	AD SUPPLY SWITCH	O	AD Power Control pin
4	SIRCS	I	Remote control signal input
5	SW-OPEN	I	Drawer open position detection signal input from CDM
6	SW-STOCK	I	Tray stock position detection signal from CDM
7	SW-CLOSE	I	Drawer close position detection signal input from CDM
8	BYTE	-	Ground terminal
9	CNVss	-	Ground terminal
10	XC-IN	I	Sub system clock input terminal (32.768kHz)
11	XC-OUT	O	Sub system clock output terminal (32.768kHz)
12	RESET	I	System reset signal input from the reset signal IC "L": reset After the power supply rises, "L" is input for several hundreds msec and then change to "H".
13	X-OUT	O	Main system clock output terminal (8MHz)
14	VSS	-	Ground terminal
15	X-IN	I	Main system clock input terminal (8MHz)
16	VCC	-	Power supply terminal (+3.3V)
17	NMI	I	Non-maskable interrupt input terminal
18	SW2	I	Disc change and mode change detection signal input from CDM
19	SW-CHUCK	I	Tray chuck position detection signal from CDM
20	AC-CUT	I	AC off detection signal input from the reset signal IC "L": AC Cut detected
21	SW1	I	Disc change and mode change detection signal input from CDM
22	SW3	I	Disc change and mode change detection signal input from CDM
23	M1+	O	Tray/drawer transportation motor control signal output
24	M2+	O	Disc change and mode change motor control signal output
25	M1-	O	Tray/drawer transportation motor control signal output
26	M2-	O	Disc change and mode change motor control signal output
27	CDM-SD	I	CDM protector detection input signal "H": protector on
28	NO-USE	-	Unused
29	IIC-CLK	I/O	Serial data transfer clock signal output terminal
30	IIC-DATA	I/O	Serial data output terminal
31	NO-USE	-	Unused
32	NO-USE	-	Unused
33	NO-USE	-	Unused
34	MTK-XIFCS	I	Chip Select Signal from MTK DMB Board
35	MTK-SOD	O	Data Out Signal to MTK DMB Board
36	MTK-SIO	I	Data In Signal from MTK DMB Board
37	MTK-CLK	I	Clock Signal from MTK DMB Board
38	MTK-RESET	O	MTK DMB Board reset pin
39	MTK-BSY	O	BUSY Signal communication between MTK Board
40	NO-USE	-	Unused
41	TC REC MUTE	O	TAPE muting control. "H": muting on (Only for African model)
42	MTK PWR CTL	O	Power Control pin for MTK DMB board
43	FAN CTRL ON/OFF	O	Fan Control Switch "H": fan on
44	MTK-VBUS-DET	O	Hub Power (V-DET) Control Port
45	MTK HUB RST	O	MTK Hub Board reset pin
46	ST-DOUT	I	PLL serial data input from the tuner unit
47	MTK-OC1	I	USB Overcurrent Detection input port 1
48	SW SPK RELAY	O	Relay drive signal output for the subwoofer "H":relay on
49	MTK-OE	O	MTK Output enable control pin
50	MTK-OC2	O	USB Overcurrent Detection input port 2
51	ST-CLK	I	PLL serial data transfer clock signal output to the tuner unit
52	ST-DIN	O	PLL serial data output to the tuner unit
53	ST-CE	O	PLL chip enable signal output to the tuner unit
54	ST-TUNED	I	Tuned detection input from the tuner unit
55	NO-USE	-	Unused
56	NO-USE	-	Unused
57	R2A15216FP-CLK	O	Serial data transfer clock signal output to audio signal processor, R2A15216FP

Pin No.	Pin Name	I/O	Description
58	R2A15216FP-DATA	O	Serial data output to audio signal processor, R2A15216FP
59	FR SPK RELAY	O	Relay drive signal output for the front speakers "H":relay on
60	STK MUTE	O	Power amplifier on/off control signal output "H": amplifier on
61	PROTECT	I	Speaker protect detection signal input from speaker protect circuit "H":protector on
62	VCC	-	Power supply terminal (+3.3V)
63	LINE-MUTE	O	Line muting on/off control signal "L":muting on
64	VSS	-	Ground terminal
65	MTK PWR MON	I	MTK DMB Board power monitor input pin (A/D input)
66	MIC/HP_DET	I	Headphone & microphone connection detection signal input (A/D input)
67	OUTPUT LEVEL DETECT	I	Speaker Output Level Detection
68	NO-USE	-	Unused
69	ILLUMINATOR-INPUT	I	Power illuminator & METER input signal detection (A/D input)
70	VACS-IN	I	VACS level detection signal (A/D input)
71	OVERVOLTAGE	I	Over-voltage protection detection input terminal "L": over-voltage detected
72	TC-STATE	I	Tape playback/recording/stop status detection input signal (A/D input) (Only for African model)
73	NO-USE	-	Unused
74	POWER/DISPLAY-KEY	I	POWER & DISPLAY key press detection signal (Interrupt input)
75	STBY RELAY	O	Main power on/off control signal output "H":power on
76	TC_M+9V SW	O	TCM power supply control signal output "H":power on (Only for African model)
77	METER-IN4	O	Meter motor control signal output 4
78	METER-IN3	O	Meter motor control signal output 3
79	METER-IN1	O	Meter motor control signal output 1
80	METER-IN2	O	Meter motor control signal output 2
81	METER SW	I	Min and Max switch input signal from METER (A/D input)
82	METER PTR LED	O	Meter Pointer LED control signal. "H" LED ON
83	METER BL CTL	O	Meter Backlight LED control signal. "H" LED ON
84	LED CTRL	O	Dynamic LED drive select signal output
85	AD-KEY2	I	Key input terminal (A/D input)
86	USB-B LED	O	Dynamic LED drive signal output to the USB B Blue & Red LED "H":LED on
87	MASTER VOL	I	Jog dial pulse input from the MASTER VOLUME encoder (A/D input)
88	LED-VOL1,2	O	Dynamic LED drive signal output to the ILLUMINATION 1st indicator and 2nd indicator "H":LED on
89	AD-KEY1	I	Key input terminal (A/D input)
90	LED-VOL5,6	O	Dynamic LED drive signal output to the ILLUMINATION 5th indicator and 6h indicator "H":LED on
91	LED-VOL3,4	O	Dynamic LED drive signal output to the ILLUMINATION 3rd indicator and 4th indicator "H":LED on
92	NO-USE	-	Unused
93	DEST-IN	I	Destination setting terminal (A/D input)
94	SW LED/USB A LED	O	Dynamic LED drive signal output to the Subwoofer LED and USB A LED indicator "H":LED on
95	STBY LED	O	LED drive signal output of POWER indicator "H":LED on
96	AVSS	-	Ground terminal (for A/D conversion)
97	AD-KEY0	I	Key input terminal (A/D input)
98	AREF	I	A/D Converter reference voltage input terminal (+3.3V)
99	AVCC	-	Power supply terminal (+3.3V) (for A/D conversion)
100	FL-DRIVER-CS	O	Serial data chip select signal to FL Driver, PT6324

## SECTION 7 EXPLODED VIEWS

**Note:**

- -XX and -X mean standardized parts, so they may have some difference from the original one.
- Items marked “\*” are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.

**• Color Indication of Appearance Parts Example:**

KNOB, BALANCE (WHITE) . . . (RED)

☒     ☒

Parts Color Cabinet's Color

The components identified by mark  or dotted line with mark  are critical for safety.

Replace only with part number specified.

**• Abbreviation**

AR : Argentine model


AUS : Australian model

E2 : 120V AC area in E model

E4 : African model


E51 : Chilean and Peruvian models

MX : Mexican model

**7-1. CASE SECTION**


Ref. No.	Part No.	Description	Remark
1	3-363-099-32	SCREW (CASE 3 TP2)	
2	4-164-374-01	CASE, SIDE-L (GVX7S)	
3	4-164-375-01	CASE, SIDE-R (GVX7S)	
#1	7-685-647-79	SCREW +BVTP 3X10 TYPE2 IT-3	

## 7-2. TOP PANEL SECTION




Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
51	3-087-053-01	+BVTP 2.6 (3CR) (E4)		59	1-797-575-11	DECK, MECHANICAL (E4)	
52	3-701-748-00	CLAMP (E4)		60	4-170-774-01	SPRING (CASS) (E4)	
53	4-164-373-01	CASE, TOP (GVX7S) (EXCEPT E4)		61	4-218-252-52	SCREW (+PTPWH M2.6), FLOATING (E4)	
54	3-047-468-01	DAMPER (E4)		62	X-2548-413-11	TOP CASE ASSY (GVX7S) (E4)	
55	2-649-132-21	BUTTON (CASS) (●, ▶, ◀, ▷, ▲, ▼) (E4)		FFC502	1-828-958-11	WIRE (FLAT TYPE) (9 CORE)	
56	3-917-753-41	CUSHION (SP) (E4)		#2	7-685-646-79	SCREW +BVTP 3X8 TYPE2 IT-3 (E4)	
57	2-688-621-01	BELT (R/F) (E4)		#3	7-685-850-04	SCREW +BVTT 2X3 (S) (E4)	
58	2-688-622-01	BELT (MAIN) (E4)					

## 7-3. LOADING PANEL SECTION, HUB BOARD SECTION, DMB19 BOARD SECTION




## 7-4. DISPLAY BOARD SECTION



Note: If wire (flat type) is replaced, install it after bending it in the same form as that before replacement.


Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
151	4-164-361-11	KNOB (VOLUME)		156	1-823-669-11	WIRE (FLAT TYPE) (11 CORE)	
152	4-164-363-11	KNOB (JOG)		157	X-2541-975-2	HOLDER (JOG) ASSY	
153	3-087-053-01	+BVTP 2.6 (3CR)		S1301	1-487-171-11	ROTARY ENCODER	
154	A-1745-602-A	METER DISPLAY ASSY (GVX)					
155	1-829-023-11	WIRE (FLAT TYPE) (23 CORE)					

## 7-5. FRONT PANEL SECTION




Ref. No.	Part No.	Description	Remark
201	2-895-507-01	KNOB (MIC)	
202	X-2541-955-1	FRONT PANEL ASSY (GVX-COM) (EXCEPT E4)	
202	X-2546-463-1	FRONT PANEL ASSY (GVX-E4) (E4)	
203	4-225-252-01	CUSHION (FOOT)	
204	3-087-053-01	+BVTP 2.6 (3CR)	
205	4-164-351-01	WINDOW (FL)	
#2	7-685-646-79	SCREW +BVTP 3X8 TYPE2 IT-3	

## 7-6. BACK PANEL SECTION



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
251	1-828-952-11	WIRE (FLAT TYPE) (9 CORE)		△ 257	1-835-068-21	CORD, POWER (AUS)	
252	1-457-369-12	CORE, FERRITE		△ 257	1-837-312-11	CORD, POWER-SUPPLY (AR)	
253	3-655-653-11	BAND (TAITON), BINDING		△ 257	1-837-344-11	CORD, POWER-SUPPLY (MX)	
254	4-966-267-12	BUSHING (FBS 001), CORD		△ 258	1-569-008-21	ADAPTOR, CONVERSION (E2, E51, E4)	
255	1-693-778-31	TUNER (FM/AM) (EXCEPT AUS)		△ M101	1-787-344-11	FAN, DC	
255	1-693-778-22	TUNER (FM/AM) (AUS)		#2	7-685-646-79	SCREW +BVTP 3X8 TYPE2 IT-3	
256	4-164-376-01	COVER FAN (GVX7S)		#5	7-685-871-01	SCREW +BVTT 3X6 (S)	
△ 257	1-777-071-83	CORD, POWER (E2, E51, E4)					


## 7-7. MAIN BOARD SECTION



Note: If wire (flat type) is replaced, install it after bending it in the same form as that before replacement.


Ref. No.	Part No.	Description	Remark
301	A-1749-832-A	MAIN BOARD, COMPLETE (E2, E51, MX, AR)	
301	A-1753-801-A	MAIN BOARD, COMPLETE (E4)	
301	A-1769-607-A	MAIN BOARD, COMPLETE (AUS)	
* 302	3-703-150-11	CLAMP	
△ M101	1-787-344-11	FAN, DC	
#2	7-685-646-79	SCREW +BVTP 3X8 TYPE2 IT-3	
#6	3-905-609-31	SCREW (TRANSISTOR)	

## 7-8. CHASSIS SECTION



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
351	4-225-252-01	CUSHION (FOOT)		▲ PT1250	1-445-825-11	POWER TRANSFORMER (MX)	
△ F1250	1-533-949-33	FUSE, T8AL 250V		△ PT1250	1-445-826-11	POWER TRANSFORMER (EXCEPT MX)	
△ F1251	1-533-949-33	FUSE, T8AL 250V		#2	7-685-646-79	SCREW +BVTP 3X8 TYPE2 IT-3	
△ F1252	1-533-949-33	FUSE, T8AL 250V		#7	7-685-880-09	SCREW +BVTT 4X6 (S)	
△ F1253	1-533-949-33	FUSE, T8AL 250V					

## 7-9. CD MECHANISM SECTION (CDM88BL-DVBU101)



Note: If wire (flat type) is replaced, install it after bending it in the same form as that before replacement.

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
401	1-840-387-31	MECHANICAL, CD		406	3-087-053-01	+BVTP 2.6 (3CR)	
402	2-632-062-11	BELT (DLM3A)		407	1-828-773-51	WIRE (FLAT TYPE) (24 CORE)	
403	2-634-618-21	INSULATOR					
404	3-087-599-01	INSULATOR SCREW					
△ 405	8-820-322-04	DEVICE, OPTICAL KHM-313CAB/C2NP (including sled motor, spindle motor)					

## DISPLAY

# SECTION 8

## ELECTRICAL PARTS LIST

## Note:

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX and -X mean standardized parts, so they may have some difference from the original one.
- Items marked "\*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- RESISTORS  
All resistors are in ohms.  
METAL: Metal-film resistor.  
METAL OXIDE: Metal oxide-film resistor.  
F: nonflammable

## • CAPACITORS

uF:  $\mu$ F

## • COILS

uH:  $\mu$ H

## • SEMICONDUCTORS

In each case, u,  $\mu$ , for example:uA... :  $\mu$ A...,  $\mu$ PA...,  $\mu$ PA...uPB... :  $\mu$ PB...,  $\mu$ PC...,  $\mu$ PC...uPD... :  $\mu$ PD...

## • Abbreviation

AR : Argentine model

AUS : Australian model

E2 : 120V AC area in E model

E4 : African model

E51 : Chilean and Peruvian models

MX : Mexican model

When indicating parts by reference number, please include the board name.

The components identified by mark ▲ or dotted line with mark ▲ are critical for safety.

Replace only with part number specified.

Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Description			Remark	
		DISPLAY BOARD				JR1008	1-216-295-91	SHORT CHIP	0			
		*****				JR1009	1-216-296-11	SHORT CHIP	0			
		< CAPACITOR >				JR1010	1-216-296-11	SHORT CHIP	0			
C1136	1-124-257-00	ELECT	2.2uF	20%	50V	JR1011	1-216-296-11	SHORT CHIP	0			
C1137	1-124-257-00	ELECT	2.2uF	20%	50V	JR1012	1-216-296-11	SHORT CHIP	0			
C1147	1-128-131-11	ELECT	22uF	20%	50V	JR1013	1-216-296-11	SHORT CHIP	0			
C1150	1-164-156-11	CERAMIC CHIP	0.1uF		25V	JR1014	1-216-864-11	SHORT CHIP	0			
C1151	1-162-927-11	CERAMIC CHIP	100PF	5%	50V	JR1015	1-216-296-11	SHORT CHIP	0			
C1152	1-162-927-11	CERAMIC CHIP	100PF	5%	50V	JR1016	1-216-296-11	SHORT CHIP	0			
C1153	1-162-927-11	CERAMIC CHIP	100PF	5%	50V	JR1017	1-216-296-11	SHORT CHIP	0			
C1155	1-126-947-11	ELECT	47uF	20%	35V	JR1018	1-216-296-11	SHORT CHIP	0			
C1156	1-164-156-11	CERAMIC CHIP	0.1uF		25V	JR1019	1-216-296-11	SHORT CHIP	0			
		< CONNECTOR >				JR1020	1-216-296-11	SHORT CHIP	0			
CN1102	1-564-720-11	PIN, CONNECTOR (SMALL TYPE) 4P				JR1021	1-216-296-11	SHORT CHIP	0			
CN1103	1-564-719-11	PIN, CONNECTOR (SMALL TYPE) 3P				JR1022	1-216-296-11	SHORT CHIP	0			
CN1105	1-784-784-11	CONNECTOR, FFC 23P				JR1023	1-216-864-11	SHORT CHIP	0			
		< DIODE >				JR1024	1-216-296-11	SHORT CHIP	0			
D1101	6-502-469-01	DI SLI-325URT31WR				JR1025	1-216-296-11	SHORT CHIP	0			
D1102	6-501-752-01	DIODE MAZ8082GMLS0				JR1026	1-216-296-11	SHORT CHIP	0			
D1104	8-719-060-27	DIODE SLR-325MCT31				JR1027	1-216-296-11	SHORT CHIP	0			
D1105	6-503-224-01	DI 1L0351V22F0MIT01				JR1028	1-216-296-11	SHORT CHIP	0			
D1106	6-503-224-01	DI 1L0351V22F0MIT01				JR1029	1-216-296-11	SHORT CHIP	0			
D1107	6-503-224-01	DI 1L0351V22F0MIT01				JR1030	1-216-296-11	SHORT CHIP	0			
D1108	6-503-224-01	DI 1L0351V22F0MIT01				JR1031	1-216-296-11	SHORT CHIP	0			
D1109	6-503-224-01	DI 1L0351V22F0MIT01				JR1032	1-216-296-11	SHORT CHIP	0			
D1110	6-503-224-01	DI 1L0351V22F0MIT01				JR1033	1-216-296-11	SHORT CHIP	0			
		< FLUORESCENT INDICATOR TUBE >				JR1034	1-216-296-11	SHORT CHIP	0			
FL1100	1-483-077-11	VACUUM FLUORESCENT DISPLAYS				JR1035	1-216-864-11	SHORT CHIP	0			
		< IC >				JR1036	1-216-864-11	SHORT CHIP	0			
IC1100	6-600-768-01	IC PNA4823M03S0						< TRANSISTOR >				
IC1101	6-713-680-01	IC PT6324-Q				Q1118	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF			
		< JUMPER RESISTOR >				Q1119	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF			
JR1001	1-216-295-91	SHORT CHIP	0			Q1120	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF			
JR1002	1-216-864-11	SHORT CHIP	0			Q1121	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF			
JR1003	1-216-295-91	SHORT CHIP	0			Q1122	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF			
JR1004	1-216-296-11	SHORT CHIP	0					< RESISTOR >				
JR1005	1-216-296-11	SHORT CHIP	0			R1100	1-216-819-11	METAL CHIP	680	5%	1/10W	
JR1006	1-216-296-11	SHORT CHIP	0			R1101	1-216-821-11	METAL CHIP	1K	5%	1/10W	
JR1007	1-216-296-11	SHORT CHIP	0			R1102	1-216-823-11	METAL CHIP	1.5K	5%	1/10W	
						R1103	1-216-823-11	METAL CHIP	1.5K	5%	1/10W	
						R1104	1-216-825-11	METAL CHIP	2.2K	5%	1/10W	
						R1105	1-216-827-11	METAL CHIP	3.3K	5%	1/10W	
						R1106	1-216-829-11	METAL CHIP	4.7K	5%	1/10W	

Ref. No.	Part No.	Description		Remark	Ref. No.	Part No.	Description		Remark		
R1107	1-218-867-11	METAL CHIP	6.8K	0.5%	1/10W	S1118	1-771-410-21	SWITCH, TACTILE (TUNER/BAND)			
R1108	1-216-833-11	METAL CHIP	10K	5%	1/10W	S1119	1-771-410-21	SWITCH, TACTILE (TAPE /PC)			
R1113	1-216-819-11	METAL CHIP	680	5%	1/10W	S1124	1-771-410-21	SWITCH, TACTILE (USB A)			
R1114	1-216-821-11	METAL CHIP	1K	5%	1/10W	S1125	1-771-410-21	SWITCH, TACTILE (RETURN)			
R1115	1-216-823-11	METAL CHIP	1.5K	5%	1/10W	S1126	1-771-410-21	SWITCH, TACTILE (REC TO USB B)			
R1116	1-216-823-11	METAL CHIP	1.5K	5%	1/10W	S1127	1-771-410-21	SWITCH, TACTILE (ENTER)			
R1117	1-216-825-11	METAL CHIP	2.2K	5%	1/10W	S1128	1-771-410-21	SWITCH, TACTILE (USB B)			
R1118	1-216-827-11	METAL CHIP	3.3K	5%	1/10W	S1129	1-771-410-21	SWITCH, TACTILE (DISC 1)			
R1119	1-216-829-11	METAL CHIP	4.7K	5%	1/10W	S1130	1-771-410-21	SWITCH, TACTILE (DISC 2)			
R1120	1-218-867-11	METAL CHIP	6.8K	0.5%	1/10W	S1131	1-771-410-21	SWITCH, TACTILE (DISC 3)			
R1121	1-216-833-11	METAL CHIP	10K	5%	1/10W	S1132	1-771-410-21	SWITCH, TACTILE ( $\Delta$ OPEN/CLOSE)			
R1158	1-216-841-11	METAL CHIP	47K	5%	1/10W	S1133	1-771-410-21	SWITCH, TACTILE (DISC SKIP/EX-CHANGE)			
R1160	1-216-841-11	METAL CHIP	47K	5%	1/10W	*****					
R1161	1-216-821-11	METAL CHIP	1K	5%	1/10W	A-1745-142-A DMB19 BOARD, COMPLETE					
R1162	1-216-819-11	METAL CHIP	680	5%	1/10W	*****					
R1163	1-216-821-11	METAL CHIP	1K	5%	1/10W	< CAPACITOR >					
R1164	1-216-823-11	METAL CHIP	1.5K	5%	1/10W	C101	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
R1165	1-216-823-11	METAL CHIP	1.5K	5%	1/10W	C102	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
R1166	1-216-825-11	METAL CHIP	2.2K	5%	1/10W	C105	1-128-994-21	ELECT CHIP	47uF	20%	10V
R1167	1-216-827-11	METAL CHIP	3.3K	5%	1/10W	C106	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
R1168	1-216-829-11	METAL CHIP	4.7K	5%	1/10W	C108	1-162-965-11	CERAMIC CHIP	0.0015uF	10%	50V
R1170	1-216-833-11	METAL CHIP	10K	5%	1/10W	C111	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
R1171	1-216-833-11	METAL CHIP	10K	5%	1/10W	C112	1-128-994-21	ELECT CHIP	47uF	20%	10V
R1173	1-216-821-11	METAL CHIP	1K	5%	1/10W	C113	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
R1174	1-216-821-11	METAL CHIP	1K	5%	1/10W	C115	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
R1189	1-216-819-11	METAL CHIP	680	5%	1/10W	C116	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
R1190	1-216-819-11	METAL CHIP	680	5%	1/10W	C118	1-124-779-00	ELECT CHIP	10uF	20%	16V
R1195	1-216-819-11	METAL CHIP	680	5%	1/10W	C119	1-137-710-91	CERAMIC CHIP	10uF	20%	6.3V
R1196	1-216-819-11	METAL CHIP	680	5%	1/10W	C124	1-165-908-11	CERAMIC CHIP	1uF	10%	10V
R1198	1-216-819-11	METAL CHIP	680	5%	1/10W	C125	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
R1199	1-216-819-11	METAL CHIP	680	5%	1/10W	C126	1-137-710-91	CERAMIC CHIP	10uF	20%	6.3V
R1201	1-216-833-11	METAL CHIP	10K	5%	1/10W	C127	1-165-908-11	CERAMIC CHIP	1uF	10%	10V
R1203	1-216-833-11	METAL CHIP	10K	5%	1/10W	C144	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
R1205	1-216-833-11	METAL CHIP	10K	5%	1/10W	C145	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
R1207	1-216-833-11	METAL CHIP	10K	5%	1/10W	C146	1-165-908-11	CERAMIC CHIP	1uF	10%	10V
R1209	1-216-809-11	METAL CHIP	100	5%	1/10W	C149	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
R1210	1-216-809-11	METAL CHIP	100	5%	1/10W	C150	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
R1211	1-216-809-11	METAL CHIP	100	5%	1/10W	C151	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
R1215	1-216-845-11	METAL CHIP	100K	5%	1/10W	C152	1-162-916-11	CERAMIC CHIP	12PF	5%	50V
< SWITCH >					C153	1-162-916-11	CERAMIC CHIP	12PF	5%	50V	
					C154	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	
S1100	1-771-410-21	SWITCH, TACTILE (I/O STANDBY)			C155	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	
S1101	1-771-410-21	SWITCH, TACTILE (DISPLAY)			C156	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	
S1102	1-771-410-21	SWITCH, TACTILE (METER MODE)			C160	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	
S1103	1-771-410-21	SWITCH, TACTILE (OPTIONS)			C168	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	
S1104	1-771-410-21	SWITCH, TACTILE (ERASE)			C169	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	
S1105	1-771-410-21	SWITCH, TACTILE (EQ BAND/SURROUND)			C172	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	
S1106	1-771-410-21	SWITCH, TACTILE (GROOVE)			C175	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	
S1107	1-771-410-21	SWITCH, TACTILE (PRESET EQ)			C179	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	
S1108	1-771-410-21	SWITCH, TACTILE (REC TIMER)			C180	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	
S1109	1-771-410-21	SWITCH, TACTILE (SUBWOOFER)			C181	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	
S1110	1-771-410-21	SWITCH, TACTILE (↔)			C183	1-165-908-11	CERAMIC CHIP	1uF	10%	10V	
S1111	1-771-410-21	SWITCH, TACTILE (CD)			C188	1-164-315-11	CERAMIC CHIP	470PF	5%	50V	
S1112	1-771-410-21	SWITCH, TACTILE (▶)			C190	1-128-995-21	ELECT CHIP	100uF	20%	10V	
S1113	1-771-410-21	SWITCH, TACTILE (◀◀◀ TUNING -)			C191	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	
S1114	1-771-410-21	SWITCH, TACTILE (USB)			C192	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	
S1115	1-771-410-21	SWITCH, TACTILE (▶▶▶ TUNING +)			C193	1-127-715-11	CERAMIC CHIP	0.22uF	10%	16V	
S1116	1-771-410-21	SWITCH, TACTILE (■)			C195	1-127-715-11	CERAMIC CHIP	0.22uF	10%	16V	
S1117	1-771-410-21	SWITCH, TACTILE (↔+)			C197	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	

## DMB19

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>			<u>Remark</u>	<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>			<u>Remark</u>
C198	1-165-908-11	CERAMIC CHIP			1uF	10%	10V			< DIODE >	
C199	1-162-968-11	CERAMIC CHIP			0.0047uF	10%	50V			< DIODE >	
C203	1-162-970-11	CERAMIC CHIP			0.01uF	10%	25V			D001 6-500-848-01 DIODE MC2840-T112-1	
C205	1-164-230-11	CERAMIC CHIP			220PF	5%	50V			D002 6-500-848-01 DIODE MC2840-T112-1	
C206	1-164-230-11	CERAMIC CHIP			220PF	5%	50V			D003 6-500-848-01 DIODE MC2840-T112-1	
C208	1-162-970-11	CERAMIC CHIP			0.01uF	10%	25V			D004 6-500-848-01 DIODE MC2840-T112-1	
C209	1-164-677-11	CERAMIC CHIP			0.033uF	10%	16V			D005 6-500-848-01 DIODE MC2840-T112-1	
C210	1-162-970-11	CERAMIC CHIP			0.01uF	10%	25V			< EARTH TERMINAL >	
C211	1-164-677-11	CERAMIC CHIP			0.033uF	10%	16V			ET001 1-780-482-11 EARTH TERMINAL	
C212	1-162-970-11	CERAMIC CHIP			0.01uF	10%	25V			ET002 1-780-482-11 EARTH TERMINAL	
C213	1-162-970-11	CERAMIC CHIP			0.01uF	10%	25V			ET003 1-780-482-11 EARTH TERMINAL	
C214	1-162-964-11	CERAMIC CHIP			0.001uF	10%	50V			ET004 1-780-482-11 EARTH TERMINAL	
C215	1-162-970-11	CERAMIC CHIP			0.01uF	10%	25V			< FERRITE BEAD >	
C216	1-162-970-11	CERAMIC CHIP			0.01uF	10%	25V			FB108 1-469-324-21 FERRITE, EMI (SMD) (2012)	
C217	1-117-681-11	ELECT CHIP			100uF	20%	16V			FB603 1-469-324-21 FERRITE, EMI (SMD) (2012)	
C218	1-128-994-21	ELECT CHIP			47uF	20%	10V			FB607 1-469-324-21 FERRITE, EMI (SMD) (2012)	
C219	1-162-970-11	CERAMIC CHIP			0.01uF	10%	25V			FB1264 1-469-118-21 FERRITE, EMI (SMD) (1608)	
C220	1-128-994-21	ELECT CHIP			47uF	20%	10V			FB1265 1-469-118-21 FERRITE, EMI (SMD) (1608)	
C221	1-164-360-11	CERAMIC CHIP			0.1uF		16V			FB1266 1-469-118-21 FERRITE, EMI (SMD) (1608)	
C222	1-164-360-11	CERAMIC CHIP			0.1uF		16V			FB1267 1-469-118-21 FERRITE, EMI (SMD) (1608)	
C224	1-162-970-11	CERAMIC CHIP			0.01uF	10%	25V			FB1268 1-469-118-21 FERRITE, EMI (SMD) (1608)	
C233	1-162-968-11	CERAMIC CHIP			0.0047uF	10%	50V			< FLUORESCENT INDICATOR TUBE >	
C502	1-125-891-11	CERAMIC CHIP			0.47uF	10%	10V			FL603 1-234-494-21 FILTER, EMI REMOVAL (SMD)	
C602	1-128-995-21	ELECT CHIP			100uF	20%	10V			< IC >	
C603	1-128-995-21	ELECT CHIP			100uF	20%	10V			IC101 6-714-821-01 IC CXD9968R (LE)	
C604	1-128-995-21	ELECT CHIP			100uF	20%	10V			IC102 (Not supplied) IC MX2L1605DM2I-12G	
C608	1-107-826-11	CERAMIC CHIP			0.1uF	10%	16V			IC104 6-714-642-01 IC EM638165 TSA-6G	
C611	1-100-566-91	CERAMIC CHIP			0.1uF	10%	25V			IC107 6-702-302-01 IC TK11133CSCL-G	
C620	1-164-360-11	CERAMIC CHIP			0.1uF		16V			IC111 6-706-838-01 IC MM1661JHBE	
C621	1-164-360-11	CERAMIC CHIP			0.1uF		16V			IC201 6-704-524-01 IC FAN8036L	
C622	1-164-360-11	CERAMIC CHIP			0.1uF		16V			IC4601 6-710-554-01 IC PCM1808PWR	
C623	1-164-360-11	CERAMIC CHIP			0.1uF		16V			IC4602 6-704-819-01 IC CS4335-KSZR	
C1504	1-162-960-11	CERAMIC CHIP			220PF	10%	50V			< TRANSISTOR >	
C1505	1-162-970-11	CERAMIC CHIP			0.01uF	10%	25V			Q101 6-550-008-01 TRANSISTOR UM6K1N-TN	
C1506	1-162-964-11	CERAMIC CHIP			0.001uF	10%	50V			Q102 6-550-653-01 TRANSISTOR QST8TR	
C1507	1-107-826-11	CERAMIC CHIP			0.1uF	10%	16V			Q103 8-729-027-52 TRANSISTOR DTC124EKA-T146	
C1512	1-107-826-11	CERAMIC CHIP			0.1uF	10%	16V			< RESISTOR >	
C4603	1-164-360-11	CERAMIC CHIP			0.1uF		16V			R101 1-216-809-11 METAL CHIP 100 5% 1/10W	
C4606	1-164-360-11	CERAMIC CHIP			0.1uF		16V			R102 1-216-864-11 SHORT CHIP 0 5% 1/10W	
C4608	1-124-779-00	ELECT CHIP			10uF	20%	16V			R103 1-218-864-11 METAL CHIP 5.1K 0.5% 1/10W	
C4622	1-162-927-11	CERAMIC CHIP			100PF	5%	50V			R107 1-216-833-11 METAL CHIP 10K 5% 1/10W	
C4623	1-162-927-11	CERAMIC CHIP			100PF	5%	50V			R108 1-216-857-11 METAL CHIP 1M 5% 1/10W	
C4626	1-162-970-11	CERAMIC CHIP			0.01uF	10%	25V			R109 1-216-809-11 METAL CHIP 100 5% 1/10W	
< CONNECTOR >											
CN101	1-815-763-32	CONNECTOR, FFC/FPC 24P					R110 1-216-841-11 METAL CHIP 47K 5% 1/10W			R111 1-216-809-11 METAL CHIP 100 5% 1/10W	
CN105	1-770-470-21	PIN, CONNECTOR (PC BOARD) 6P					R112 1-211-977-11 METAL CHIP 22 0.5% 1/10W			R113 1-211-977-11 METAL CHIP 22 0.5% 1/10W	
CN201	1-770-161-21	PIN, CONNECTOR (PC BOARD) 6P					R114 1-216-845-11 METAL CHIP 100K 5% 1/10W			R115 1-211-977-11 METAL CHIP 22 0.5% 1/10W	
CN601	1-778-795-21	PIN, CONNECTOR (PC BOARD) 9P					R116 1-216-821-11 METAL CHIP 1K 5% 1/10W			R117 1-216-841-11 METAL CHIP 47K 5% 1/10W	
* CN1105	1-750-005-11	PIN, CONNECTOR (PC BOARD) 4P					R118 1-216-801-11 METAL CHIP 22 5% 1/10W			R120 1-216-801-11 METAL CHIP 22 5% 1/10W	
CN1106	1-784-861-51	CONNECTOR, FFC (LIF (NON-ZIF)) 9P					R121 1-216-801-11 METAL CHIP 22 5% 1/10W			R122 1-216-833-11 METAL CHIP 10K 5% 1/10W	
CN4602	1-784-859-51	CONNECTOR, FFC (LIF (NON-ZIF)) 7P									

Note: When IC102 cannot exchange with single. When this part is damaged, exchange the entire mounted board.

Ref. No.	Part No.	Description		Remark	Ref. No.	Part No.	Description		Remark	
R123	1-216-809-11	METAL CHIP	100	5%	1/10W	R1255	1-216-295-91	SHORT CHIP	0	
R124	1-216-841-11	METAL CHIP	47K	5%	1/10W	R1256	1-216-295-91	SHORT CHIP	0	
R125	1-216-833-11	METAL CHIP	10K	5%	1/10W	R1261	1-216-833-11	METAL CHIP	10K	5% 1/10W
R133	1-216-864-11	SHORT CHIP	0			R1262	1-216-833-11	METAL CHIP	10K	5% 1/10W
R136	1-216-835-11	METAL CHIP	15K	5%	1/10W	R1263	1-216-864-11	SHORT CHIP	0	
R142	1-216-845-11	METAL CHIP	100K	5%	1/10W	R1269	1-216-809-11	METAL CHIP	100	5% 1/10W
R156	1-216-809-11	METAL CHIP	100	5%	1/10W	R1276	1-216-864-11	SHORT CHIP	0	
R204	1-216-822-11	METAL CHIP	1.2K	5%	1/10W	R1277	1-216-809-11	METAL CHIP	100	5% 1/10W
R205	1-216-833-11	METAL CHIP	10K	5%	1/10W	R1278	1-216-833-11	METAL CHIP	10K	5% 1/10W
R206	1-216-833-11	METAL CHIP	10K	5%	1/10W	R1279	1-216-833-11	METAL CHIP	10K	5% 1/10W
R207	1-216-826-11	METAL CHIP	2.7K	5%	1/10W	R1280	1-216-864-11	SHORT CHIP	0	
R208	1-216-839-11	METAL CHIP	33K	5%	1/10W	R1281	1-216-864-11	SHORT CHIP	0	
R209	1-216-839-11	METAL CHIP	33K	5%	1/10W	R1282	1-216-864-11	SHORT CHIP	0	
R210	1-216-841-11	METAL CHIP	47K	5%	1/10W	R1283	1-216-864-11	SHORT CHIP	0	
R212	1-216-833-11	METAL CHIP	10K	5%	1/10W	R4601	1-216-809-11	METAL CHIP	100	5% 1/10W
R213	1-218-867-11	METAL CHIP	6.8K	0.5%	1/10W	R4602	1-216-809-11	METAL CHIP	100	5% 1/10W
R214	1-216-835-11	METAL CHIP	15K	5%	1/10W	R4605	1-469-112-11	FERRITE, EMI (SMD) (1608)		
R215	1-216-834-11	METAL CHIP	12K	5%	1/10W	R4606	1-216-801-11	METAL CHIP	22	5% 1/10W
R216	1-216-834-11	METAL CHIP	12K	5%	1/10W	R4608	1-216-864-11	SHORT CHIP	0	
R219	1-216-838-11	METAL CHIP	27K	5%	1/10W	R4609	1-216-864-11	SHORT CHIP	0	
R220	1-216-821-11	METAL CHIP	1K	5%	1/10W	R4611	1-216-864-11	SHORT CHIP	0	
R221	1-218-889-11	METAL CHIP	56K	0.5%	1/10W	R4833	1-216-864-11	SHORT CHIP	0	
R223	1-218-895-11	METAL CHIP	100K	0.5%	1/10W	R4834	1-216-864-11	SHORT CHIP	0	
R224	1-216-833-11	METAL CHIP	10K	5%	1/10W	R4835	1-216-295-91	SHORT CHIP	0	
R225	1-218-895-11	METAL CHIP	100K	0.5%	1/10W	R4837	1-216-864-11	SHORT CHIP	0	
R226	1-218-889-11	METAL CHIP	56K	0.5%	1/10W	R4838	1-216-864-11	SHORT CHIP	0	
R230	1-218-893-11	METAL CHIP	82K	0.5%	1/10W					< COMPOSITION CIRCUIT BLOCK >
R231	1-218-875-11	METAL CHIP	15K	0.5%	1/10W	RB105	1-234-400-21	CONDUCTOR, NETWORK (100X4)		
R232	1-218-877-11	METAL CHIP	18K	0.5%	1/10W	RB106	1-234-400-21	CONDUCTOR, NETWORK (100X4)		
R233	1-218-883-11	METAL CHIP	33K	0.5%	1/10W	RB107	1-234-400-21	CONDUCTOR, NETWORK (100X4)		
R234	1-216-833-11	METAL CHIP	10K	5%	1/10W	RB108	1-234-400-21	CONDUCTOR, NETWORK (100X4)		
R246	1-216-829-11	METAL CHIP	4.7K	5%	1/10W	RB111	1-234-400-21	CONDUCTOR, NETWORK (100X4)		
R247	1-216-821-11	METAL CHIP	1K	5%	1/10W	RB112	1-234-400-21	CONDUCTOR, NETWORK (100X4)		
R256	1-216-833-11	METAL CHIP	10K	5%	1/10W	RB113	1-234-400-21	CONDUCTOR, NETWORK (100X4)		
R521	1-216-833-11	METAL CHIP	10K	5%	1/10W	RB114	1-234-400-21	CONDUCTOR, NETWORK (100X4)		
R605	1-216-295-91	SHORT CHIP	0			RB115	1-234-400-21	CONDUCTOR, NETWORK (100X4)		
R606	1-216-295-91	SHORT CHIP	0							
R608	1-216-295-91	SHORT CHIP	0							< VIBRATOR >
R630	1-216-295-91	SHORT CHIP	0			X101	1-814-103-21	VIBRATOR, CRYSTAL (27 MHz)		
R1101	1-218-841-11	METAL CHIP	560	0.5%	1/10W					*****
R1110	1-216-826-11	METAL CHIP	2.7K	5%	1/10W					
R1114	1-500-903-21	EMI FERRITE (SMD)				A-1750-170-A	HUB BOARD, COMPLETE			
R1121	1-216-864-11	SHORT CHIP	0							*****
R1123	1-216-864-11	SHORT CHIP	0							
R1129	1-216-845-11	METAL CHIP	100K	5%	1/10W					< CAPACITOR >
R1150	1-216-827-11	METAL CHIP	3.3K	5%	1/10W	C1500	1-100-597-91	CERAMIC CHIP	0.1uF	10% 25V
R1151	1-216-827-11	METAL CHIP	3.3K	5%	1/10W	C1501	1-165-989-11	CERAMIC CHIP	10uF	10% 6.3V
R1152	1-216-827-11	METAL CHIP	3.3K	5%	1/10W	C1502	1-100-597-91	CERAMIC CHIP	0.1uF	10% 25V
R1168	1-218-835-11	METAL CHIP	330	0.5%	1/10W	C1503	1-162-915-11	CERAMIC CHIP	10PF	0.5PF 50V
R1177	1-216-864-11	SHORT CHIP	0			C1504	1-162-919-11	CERAMIC CHIP	22PF	5% 50V
R1178	1-216-821-11	METAL CHIP	1K	5%	1/10W	C1505	1-162-970-11	CERAMIC CHIP	0.01uF	10% 25V
R1184	1-216-809-11	METAL CHIP	100	5%	1/10W	C1506	1-162-970-11	CERAMIC CHIP	0.01uF	10% 25V
R1191	1-216-864-11	SHORT CHIP	0			C1507	1-100-597-91	CERAMIC CHIP	0.1uF	10% 25V
R1192	1-216-864-11	SHORT CHIP	0			C1508	1-165-989-11	CERAMIC CHIP	10uF	10% 6.3V
R1193	1-216-864-11	SHORT CHIP	0			C1510	1-100-597-91	CERAMIC CHIP	0.1uF	10% 25V
R1194	1-216-864-11	SHORT CHIP	0			C1511	1-162-970-11	CERAMIC CHIP	0.01uF	10% 25V
R1248	1-216-295-91	SHORT CHIP	0			C1512	1-165-989-11	CERAMIC CHIP	10uF	10% 6.3V
R1249	1-216-821-11	METAL CHIP	1K	5%	1/10W	C1513	1-162-970-11	CERAMIC CHIP	0.01uF	10% 25V
R1250	1-216-295-91	SHORT CHIP	0			C1514	1-165-989-11	CERAMIC CHIP	10uF	10% 6.3V
R1252	1-216-295-91	SHORT CHIP	0			C1515	1-162-970-11	CERAMIC CHIP	0.01uF	10% 25V

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>			<u>Remark</u>	<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>			<u>Remark</u>									
C1516	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	R1527	1-216-809-11	METAL CHIP	100	5%	1/10W									
C1517	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V	R1530	1-216-857-11	METAL CHIP	1M	5%	1/10W									
C1518	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V	R1533	1-216-845-11	METAL CHIP	100K	5%	1/10W									
C1519	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	R1537	1-216-845-11	METAL CHIP	100K	5%	1/10W									
C1520	1-137-765-21	ELECT CHIP	47uF	20%	16V	R1538	1-216-845-11	METAL CHIP	100K	5%	1/10W									
C1521	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	R1540	1-216-845-11	METAL CHIP	100K	5%	1/10W									
C1522	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V	R1541	1-216-809-11	METAL CHIP	100	5%	1/10W									
C1523	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V	R1542	1-216-845-11	METAL CHIP	100K	5%	1/10W									
C1524	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V	R1543	1-216-833-11	METAL CHIP	10K	5%	1/10W									
C1527	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V	R1544	1-216-833-11	METAL CHIP	10K	5%	1/10W									
C1528	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V	R1546	1-216-809-11	METAL CHIP	100	5%	1/10W									
C1529	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V	R1547	1-216-834-11	METAL CHIP	12K	5%	1/10W									
C1530	1-162-910-11	CERAMIC CHIP	5PF	0.25PF	50V	< VIBRATOR >														
C1531	1-162-910-11	CERAMIC CHIP	5PF	0.25PF	50V	X1500	1-760-613-21	VIBRATOR, CRYSTAL (24MHz)												
*****																				
CN1500	1-774-731-21	PIN, CONNECTOR (PC BOARD) 5P				A-1749-832-A	MAIN BOARD, COMPLETE (E2, E51, MX, AR)													
CN1501	1-774-729-21	PIN, CONNECTOR (PC BOARD) 10P				A-1753-801-A	MAIN BOARD, COMPLETE (E4)													
CN1502	1-785-728-21	PIN (PC BOARD), CONNECTOR 7P				A-1769-607-A	MAIN BOARD, COMPLETE (AUS)													
*****																				
< EARTH TERMINAL >																				
* ET1500	1-780-408-11	TERMINAL, LUG				7-685-646-79	SCREW +BVTP 3X8 TYPE2 IT-3													
* ET1501	1-780-408-11	TERMINAL, LUG				< CAPACITOR >														
< FERRITE BEAD >																				
* FB1500	1-400-973-21	INDUCTOR (EMI FERRITE)				C002	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V									
FB1501	1-216-295-91	SHORT CHIP	0			C005	1-162-966-11	CERAMIC CHIP	0.0022uF	10%	50V									
* FB1502	1-400-973-21	INDUCTOR (EMI FERRITE)				C014	1-162-966-11	CERAMIC CHIP	0.0022uF	10%	50V									
FB1503	1-216-295-91	SHORT CHIP	0			C021	1-104-658-91	ELECT	100uF	20%	10V									
* FB1505	1-400-973-21	INDUCTOR (EMI FERRITE)				C040	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V									
< IC >																				
IC1500	8-759-338-95	IC NJM2903V (TE2)				C041	1-126-933-11	ELECT	100uF	20%	16V									
IC1501	6-714-034-01	IC USB2512A-AEZG				C073	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V									
< RESISTOR >																				
R1500	1-216-809-11	METAL CHIP	100	5%	1/10W	C074	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V									
R1501	1-216-837-11	METAL CHIP	22K	5%	1/10W	C077	1-126-961-11	ELECT	2.2uF	20%	50V									
R1503	1-216-815-11	METAL CHIP	330	5%	1/10W	C081	1-128-953-31	ELECT	470uF	20%	25V									
R1504	1-218-446-11	METAL CHIP	1	5%	1/10W	C083	1-135-372-31	ELECT	470uF	20%	10V									
R1505	1-218-446-11	METAL CHIP	1	5%	1/10W	C086	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V									
R1506	1-218-446-11	METAL CHIP	1	5%	1/10W	C090	1-126-951-11	ELECT	470uF	20%	35V									
R1507	1-218-446-11	METAL CHIP	1	5%	1/10W	C092	1-128-949-31	ELECT	470uF	20%	16V									
R1508	1-218-446-11	METAL CHIP	1	5%	1/10W	C095	1-126-951-11	ELECT	470uF	20%	35V									
R1509	1-218-446-11	METAL CHIP	1	5%	1/10W	C097	1-135-372-31	ELECT	470uF	20%	10V									
R1510	1-218-446-11	METAL CHIP	1	5%	1/10W	C100	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V									
R1506	1-218-446-11	METAL CHIP	1	5%	1/10W	C102	1-126-963-11	ELECT	4.7uF	20%	50V									
R1507	1-218-446-11	METAL CHIP	1	5%	1/10W	C105	1-162-967-11	CERAMIC CHIP	0.0033uF	10%	50V									
R1508	1-218-446-11	METAL CHIP	1	5%	1/10W	C109	1-126-964-11	ELECT	10uF	20%	50V									
R1509	1-218-446-11	METAL CHIP	1	5%	1/10W	C120	1-100-385-91	CERAMIC CHIP	0.47uF		25V									
R1510	1-218-446-11	METAL CHIP	1	5%	1/10W	C124	1-126-960-11	ELECT	1uF	20%	50V									
R1511	1-218-446-11	METAL CHIP	1	5%	1/10W	C127	1-137-190-91	FILM	0.22uF	5%	50V									
R1512	1-218-446-11	METAL CHIP	1	5%	1/10W	C128	1-137-189-11	FILM	0.18uF	5%	50V									
R1513	1-218-446-11	METAL CHIP	1	5%	1/10W	C131	1-126-964-11	ELECT	10uF	20%	50V									
R1515	1-216-837-11	METAL CHIP	22K	5%	1/10W	C132	1-136-161-00	FILM	0.047uF	5%	50V									
R1516	1-216-815-11	METAL CHIP	330	5%	1/10W	C133	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V									
R1517	1-218-446-11	METAL CHIP	1	5%	1/10W	C134	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V									
R1518	1-218-446-11	METAL CHIP	1	5%	1/10W	C135	1-164-173-11	CERAMIC CHIP	0.0039uF	10%	50V									
R1519	1-218-446-11	METAL CHIP	1	5%	1/10W	C137	1-126-964-11	ELECT	10uF	20%	50V									
R1520	1-218-446-11	METAL CHIP	1	5%	1/10W	C141	1-126-964-11	ELECT	10uF	20%	50V									
R1521	1-218-446-11	METAL CHIP	1	5%	1/10W	C142	1-117-720-11	CERAMIC CHIP	4.7uF		10V									
R1522	1-218-446-11	METAL CHIP	1	5%	1/10W	C143	1-117-720-11	CERAMIC CHIP	4.7uF		(E4)									
R1523	1-218-446-11	METAL CHIP	1	5%	1/10W	C144	1-117-720-11	CERAMIC CHIP	4.7uF		10V									
R1524	1-218-446-11	METAL CHIP	1	5%	1/10W	C146	1-117-720-11	CERAMIC CHIP	4.7uF		10V									
R1525	1-218-446-11	METAL CHIP	1	5%	1/10W															
R1526	1-218-446-11	METAL CHIP	1	5%	1/10W															

MAIN

Ref. No.	Part No.	Description		Remark	Ref. No.	Part No.	Description		Remark			
C147	1-126-959-11	ELECT	0.47uF	20%	50V	C292	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	
C148	1-104-658-91	ELECT	100uF	20%	10V	C294	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V	
C149	1-126-947-11	ELECT	47uF	20%	35V	C350	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V	
C150	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V	C351	1-126-964-11	ELECT	10uF	20%	50V	
C151	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V	C352	1-128-934-11	CERAMIC CHIP	0.33uF	20%	10V	
C152	1-100-756-91	CERAMIC CHIP	0.047uF	10%	50V	C353	1-126-964-11	ELECT	10uF	20%	50V	
C153	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V	C354	1-126-157-11	ELECT	10uF	20%	16V	
C154	1-126-925-91	ELECT	470uF	20%	10V	C355	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V	
C155	1-162-967-11	CERAMIC CHIP	0.0033uF	10%	50V	C360	1-126-964-11	ELECT	10uF	20%	50V	
C177	1-137-190-91	FILM	0.22uF	5%	50V	C362	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V	
C178	1-137-189-11	FILM	0.18uF	5%	50V	C392	1-162-963-11	CERAMIC CHIP	680PF	10%	50V	
C181	1-126-964-11	ELECT	10uF	20%	50V	C393	1-162-919-11	CERAMIC CHIP	22PF	5%	50V	
C182	1-136-161-00	FILM	0.047uF	5%	50V	C395	1-162-919-11	CERAMIC CHIP	22PF	5%	50V	
C183	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V	C396	1-162-919-11	CERAMIC CHIP	22PF	5%	50V	
C184	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	C397	1-162-919-11	CERAMIC CHIP	22PF	5%	50V	
C185	1-164-173-11	CERAMIC CHIP	0.0039uF	10%	50V	C398	1-162-919-11	CERAMIC CHIP	22PF	5%	50V	
C187	1-126-964-11	ELECT	10uF	20%	50V	(E4)	C399	1-162-919-11	CERAMIC CHIP	22PF	5%	50V
C191	1-126-964-11	ELECT	10uF	20%	50V	(E4)	C405	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V
C192	1-117-720-11	CERAMIC CHIP	4.7uF		10V	(E4)	C406	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V
C193	1-117-720-11	CERAMIC CHIP	4.7uF		10V	(E4)	C407	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V
C194	1-117-720-11	CERAMIC CHIP	4.7uF		10V	(E4)	C410	1-162-918-11	CERAMIC CHIP	18PF	5%	50V
C201	1-126-961-11	ELECT	2.2uF	20%	50V	(E4)	C411	1-162-920-11	CERAMIC CHIP	27PF	5%	50V
C208	1-117-720-11	CERAMIC CHIP	4.7uF		10V	(E4)	C414	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V
C209	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V	(E4)	C418	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V
C212	1-164-505-11	CERAMIC CHIP	2.2uF		16V	(E4)	C419	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V
C214	1-164-505-11	CERAMIC CHIP	2.2uF		16V	(E4)	C421	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V
C215	1-164-505-11	CERAMIC CHIP	2.2uF		16V	(E4)	C422	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V
C218	1-126-947-11	ELECT	47uF	20%	35V	(E4)	C434	1-162-923-11	CERAMIC CHIP	47PF	5%	50V
C219	1-117-720-11	CERAMIC CHIP	4.7uF		10V	(E4)	C435	1-162-923-11	CERAMIC CHIP	47PF	5%	50V
C220	1-126-947-11	ELECT	47uF	20%	35V	(E4)	C436	1-162-923-11	CERAMIC CHIP	47PF	5%	50V
C221	1-126-964-11	ELECT	10uF	20%	50V	(E4)	C437	1-162-923-11	CERAMIC CHIP	47PF	5%	50V
C222	1-162-923-11	CERAMIC CHIP	47PF	5%	50V	(E4)	C438	1-162-923-11	CERAMIC CHIP	47PF	5%	50V
C223	1-162-919-11	CERAMIC CHIP	22PF	5%	50V	(E4)	C439	1-162-923-11	CERAMIC CHIP	47PF	5%	50V
C224	1-126-960-11	ELECT	1uF	20%	50V	(E4)	C446	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V
C227	1-126-964-11	ELECT	10uF	20%	50V	(E4)	C472	1-115-339-11	CERAMIC CHIP	0.1uF	10%	50V
C229	1-126-964-11	ELECT	10uF	20%	50V	(E4)	C498	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V
C231	1-136-162-00	FILM	0.056uF	5%	50V	(E4)	C501	1-162-923-11	CERAMIC CHIP	47PF	5%	50V
C234	1-110-563-11	CERAMIC CHIP	0.068uF	10%	16V	(E4)	C502	1-162-962-11	CERAMIC CHIP	470PF	10%	50V
C236	1-131-664-91	CERAMIC CHIP	0.15uF	10%	10V	(E4)	C503	1-162-962-11	CERAMIC CHIP	470PF	10%	50V
C239	1-131-664-91	CERAMIC CHIP	0.15uF	10%	10V	(E4)	C504	1-162-962-11	CERAMIC CHIP	470PF	10%	50V
C242	1-125-891-11	CERAMIC CHIP	0.47uF	10%	10V	(E4)	C505	1-162-962-11	CERAMIC CHIP	470PF	10%	50V
C258	1-117-720-11	CERAMIC CHIP	4.7uF		10V	(E4)	C507	1-162-927-11	CERAMIC CHIP	100PF	5%	50V
C265	1-164-505-11	CERAMIC CHIP	2.2uF		16V	(E4)	C508	1-162-962-11	CERAMIC CHIP	470PF	10%	50V
C268	1-126-947-11	ELECT	47uF	20%	35V	(E4)	C509	1-162-962-11	CERAMIC CHIP	470PF	10%	50V
C269	1-117-720-11	CERAMIC CHIP	4.7uF		10V	(E4)	C516	1-126-917-11	ELECT	3300uF	20%	6.3V
C270	1-126-947-11	ELECT	47uF	20%	35V	(E4)	C543	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V
C272	1-162-923-11	CERAMIC CHIP	47PF	5%	50V	(E4)	C551	1-162-923-11	CERAMIC CHIP	47PF	5%	50V
C273	1-162-919-11	CERAMIC CHIP	22PF	5%	50V	(E4)	C552	1-162-962-11	CERAMIC CHIP	470PF	10%	50V
C274	1-126-960-11	ELECT	1uF	20%	50V	(E4)	C553	1-162-962-11	CERAMIC CHIP	470PF	10%	50V
C275	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V	(E4)	C554	1-162-962-11	CERAMIC CHIP	470PF	10%	50V
C276	1-126-925-91	ELECT	470uF	20%	10V	(E4)	C555	1-162-962-11	CERAMIC CHIP	470PF	10%	50V
C277	1-126-964-11	ELECT	10uF	20%	50V	(E4)	C557	1-162-927-11	CERAMIC CHIP	100PF	5%	50V
C279	1-126-964-11	ELECT	10uF	20%	50V	(E4)	C602	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V
C281	1-136-162-00	FILM	0.056uF	5%	50V	(E4)	C603	1-104-658-91	ELECT	100uF	20%	10V
C284	1-110-563-11	CERAMIC CHIP	0.068uF	10%	16V	(E4)	C605	1-136-153-00	FILM	0.01uF	5%	50V
C285	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V	(E4)	C606	1-136-153-00	FILM	0.01uF	5%	50V
C286	1-131-664-91	CERAMIC CHIP	0.15uF	10%	10V	(E4)	C607	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V
C289	1-131-664-91	CERAMIC CHIP	0.15uF	10%	10V	(E4)	C608	1-126-944-11	ELECT	3300uF	20%	25V
C290	1-104-658-91	ELECT	100uF	20%	10V	(E4)	C655	1-126-923-91	ELECT	220uF	20%	10V
C291	1-126-925-91	ELECT	470uF	20%	10V	(E4)						

## MAIN

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>			<u>Remark</u>	<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>			<u>Remark</u>
C656	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V	IC253	8-759-278-58	IC	NJM4558V-TE2		
C697	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V	IC254	8-759-278-58	IC	NJM4558V-TE2		
C698	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V	IC255	8-759-278-58	IC	NJM4558V-TE2		
C699	1-126-964-11	ELECT	10uF	20%	50V	IC400	6-712-027-01	IC	R2A15216FP		
		< CONNECTOR >				IC401	A-1779-246-A	IC	R5F364AEDFA (for SERVICE)		
< JACK >											
* CN090	1-564-725-11	PIN, CONNECTOR (SMALL TYPE) 9P				J020	1-822-758-11	JACK, PIN 2P (PC IN)			
CN100	1-766-715-21	CONNECTOR, BOARD TO BOARD 10P						< JUMPER RESISTOR >			
CN200	1-573-843-11	CONNECTOR, BOARD TO BOARD 11P				JR001	1-216-864-11	SHORT CHIP	0		
CN220	1-784-770-11	CONNECTOR, FFC 9P				JR003	1-216-296-11	SHORT CHIP	0		
CN402	1-779-277-11	CONNECTOR, FFC (LIF (NON-ZIF)) 9P				JR004	1-216-296-11	SHORT CHIP	0		
CN403	1-568-830-11	CONNECTOR, FFC 11P				JR005	1-216-864-11	SHORT CHIP	0		
CN405	1-784-784-11	CONNECTOR, FFC 23P				JR006	1-216-296-11	SHORT CHIP	0		
CN410	1-784-774-11	CONNECTOR, FFC 13P				JR007	1-216-296-11	SHORT CHIP	0		
CN450	1-784-770-11	CONNECTOR, FFC 9P (E4)				JR008	1-216-864-11	SHORT CHIP	0		
CN470	1-564-709-11	PIN, CONNECTOR (SMALL TYPE) 7P				JR009	1-216-296-11	SHORT CHIP	0		
CN550	1-778-226-21	CONNECTOR, BOARD TO BOARD 6P				JR010	1-216-864-11	SHORT CHIP	0		
* CN600	1-564-506-11	PLUG, CONNECTOR 3P				JR011	1-216-864-11	SHORT CHIP	0		
CN650	1-784-923-11	PIN, CONNECTOR 7P				JR012	1-216-864-11	SHORT CHIP	0		
CN680	1-779-275-11	CONNECTOR, FFC (LIF (NON-ZIF)) 7P				JR013	1-216-864-11	SHORT CHIP	0		
CN690	1-779-277-11	CONNECTOR, FFC (LIF (NON-ZIF)) 9P				JR014	1-216-296-11	SHORT CHIP	0		
CN691	1-785-316-11	PIN, CONNECTOR (STRAIGHT) 4P				JR015	1-216-864-11	SHORT CHIP	0		
	< DIODE >					JR016	1-216-296-11	SHORT CHIP	0		
D010	6-501-817-01	DIODE MA2J1110GLS0				JR017	1-216-296-11	SHORT CHIP	0		
D077	6-500-335-01	DIODE MC2838-T112-1				JR018	1-216-296-11	SHORT CHIP	0		
D081	6-502-272-01	DI RB055L-40TE25				JR019	1-216-296-11	SHORT CHIP	0		
D091	6-502-272-01	DI RB055L-40TE25				JR020	1-216-864-11	SHORT CHIP	0		
D096	6-502-272-01	DI RB055L-40TE25				JR021	1-216-296-11	SHORT CHIP	0		
D104	6-501-817-01	DIODE MA2J1110GLS0				JR022	1-216-296-11	SHORT CHIP	0		
D116	6-500-848-01	DIODE MC2840-T112-1				JR023	1-216-864-11	SHORT CHIP	0		
D201	6-500-848-01	DIODE MC2840-T112-1				JR024	1-216-296-11	SHORT CHIP	0		
D290	6-501-817-01	DIODE MA2J1110GLS0				JR025	1-216-296-11	SHORT CHIP	0		
D350	6-501-817-01	DIODE MA2J1110GLS0				JR026	1-216-864-11	SHORT CHIP	0		
D351	6-500-334-01	DIODE MC2836-T112-1				JR027	1-216-296-11	SHORT CHIP	0		
D352	6-501-722-01	DIODE MAZ8043GMLS0				JR028	1-216-296-11	SHORT CHIP	0		
D360	6-501-734-01	DIODE MAZ8056GMLS0				JR029	1-216-296-11	SHORT CHIP	0		
D362	6-500-522-21	DIODE 10EDB40-TB3				JR030	1-216-864-11	SHORT CHIP	0		
D363	6-500-522-21	DIODE 10EDB40-TB3				JR031	1-216-296-11	SHORT CHIP	0		
D392	6-501-579-01	DIODE MC2837				JR032	1-216-864-11	SHORT CHIP	0		
D467	6-501-713-01	DIODE MAZ8033GOLS0				JR033	1-216-296-11	SHORT CHIP	0		
D566	6-500-335-01	DIODE MC2838-T112-1				JR034	1-216-864-11	SHORT CHIP	0		
D571	6-500-335-01	DIODE MC2838-T112-1				JR035	1-216-296-11	SHORT CHIP	0		
D600	6-502-994-01	DI D10XB60 F				JR036	1-216-296-11	SHORT CHIP	0		
D623	6-500-522-21	DIODE 10EDB40-TB3				JR037	1-216-864-11	SHORT CHIP	0		
D624	6-500-522-21	DIODE 10EDB40-TB3				JR038	1-216-296-11	SHORT CHIP	0		
D651	6-500-522-21	DIODE 10EDB40-TB3				JR039	1-216-864-11	SHORT CHIP	0		
D652	6-500-522-21	DIODE 10EDB40-TB3				JR040	1-216-864-11	SHORT CHIP	0		
D653	6-500-522-21	DIODE 10EDB40-TB3				JR041	1-216-864-11	SHORT CHIP	0		
D692	6-501-734-01	DIODE MAZ8056GMLS0				JR042	1-216-864-11	SHORT CHIP	0		
	< IC >					JR043	1-216-296-11	SHORT CHIP	0		
IC040	6-713-034-01	IC KIA7812API-U/PF				JR044	1-216-296-11	SHORT CHIP	0		
IC055	6-713-826-01	IC SI-8001FFEK				JR045	1-216-864-11	SHORT CHIP	0		
IC065	6-712-617-01	IC SI-8008TM-TLS				JR046	1-216-296-11	SHORT CHIP	0		
IC075	6-712-617-01	IC SI-8008TM-TLS				JR047	1-216-296-11	SHORT CHIP	0		
IC200	6-713-032-01	IC KIA7809API-U/PF				JR048	1-216-296-11	SHORT CHIP	0		
IC251	8-759-278-58	IC NJM4558V-TE2				JR050	1-216-864-11	SHORT CHIP	0		
IC252	8-759-278-58	IC NJM4558V-TE2				JR051	1-216-864-11	SHORT CHIP	0		
						JR052	1-216-296-11	SHORT CHIP	0		

MAIN

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
JR053	1-216-296-11	SHORT CHIP	0	Q655	8-729-040-76	TRANSISTOR	KTA1273-Y-AT
JR054	1-216-296-11	SHORT CHIP	0	Q656	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF
JR055	1-216-296-11	SHORT CHIP	0	Q657	6-551-696-01	TRANSISTOR	ISA1235AC1TP-1EF
JR056	1-216-864-11	SHORT CHIP	0	Q658	6-551-696-01	TRANSISTOR	ISA1235AC1TP-1EF
JR057	1-216-864-11	SHORT CHIP	0	Q681	6-551-276-01	TRANSISTOR	RT1N431C-TP-1 (E4)
JR058	1-216-864-11	SHORT CHIP	0	Q684	8-729-037-13	TRANSISTOR	KTA1271Y (E4)
JR059	1-216-296-11	SHORT CHIP	0	Q696	8-729-032-94	TRANSISTOR	2SD1859TV2Q
JR060	1-216-864-11	SHORT CHIP	0				< RESISTOR >
JR061	1-216-864-11	SHORT CHIP	0 (E4)	R001	1-215-892-11	METAL OXIDE	1K 5% 2W
JR070	1-216-864-11	SHORT CHIP	0	R002	1-246-024-21	METAL CHIP	150 5% 1/2W
JR361	1-216-864-11	SHORT CHIP	0	R005	1-216-801-11	METAL CHIP	22 5% 1/10W
JR406	1-216-296-11	SHORT CHIP	0	R026	1-216-827-11	METAL CHIP	3.3K 5% 1/10W
JR651	1-216-864-11	SHORT CHIP	0	R026	1-216-830-11	METAL CHIP	(AUS)
JR687	1-216-864-11	SHORT CHIP	0	R026	1-216-830-11	METAL CHIP	5.6K 5% 1/10W (E2, E51, MX, AR)
JR688	1-216-864-11	SHORT CHIP	0				
			< COIL >	R026	1-216-827-11	METAL CHIP	3.3K 5% 1/10W (E4)
L083	1-400-424-21	INDUCTOR	47uH	R027	1-216-830-11	METAL CHIP	5.6K 5% 1/10W (AUS)
L092	1-457-822-11	INDUCTOR	47uH	R027	1-216-829-11	METAL CHIP	4.7K 5% 1/10W (E2, E51, MX, AR)
L097	1-400-424-21	INDUCTOR	47uH	R027	1-216-830-11	METAL CHIP	5.6K 5% 1/10W (E4)
			< TRANSISTOR >	R028	1-216-827-11	METAL CHIP	3.3K 5% 1/10W (AUS)
Q030	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF	R028	1-216-830-11	METAL CHIP	5.6K 5% 1/10W (E2, E51, MX, AR)
Q031	8-729-924-99	TRANSISTOR	2SC3722K-E	R028	1-216-827-11	METAL CHIP	3.3K 5% 1/10W (E4)
Q032	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF	R028	1-216-827-11	METAL CHIP	3.3K 5% 1/10W (AUS)
Q033	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF	R028	1-216-830-11	METAL CHIP	5.6K 5% 1/10W (E2, E51, MX, AR)
Q062	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF (E4)	R028	1-216-827-11	METAL CHIP	4.7K 5% 1/10W (E4)
Q063	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF (E4)	R028	1-216-830-11	METAL CHIP	5.6K 5% 1/10W (E2, E51, MX, AR)
Q090	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF	R028	1-216-827-11	METAL CHIP	3.3K 5% 1/10W (E4)
Q128	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF	R029	1-216-830-11	METAL CHIP	5.6K 5% 1/10W (AUS)
Q178	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF	R029	1-216-829-11	METAL CHIP	4.7K 5% 1/10W (E2, E51, MX, AR)
Q210	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF	R029	1-216-830-11	METAL CHIP	5.6K 5% 1/10W (E4)
Q220	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF	R030	1-216-821-11	METAL CHIP	1K 5% 1/10W
Q230	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF	R032	1-216-821-11	METAL CHIP	1K 5% 1/10W
Q245	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF	R033	1-216-821-11	METAL CHIP	1K 5% 1/10W
Q270	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF	R035	1-216-821-11	METAL CHIP	1K 5% 1/10W
Q290	8-729-027-23	TRANSISTOR	DTA114EKA-T146	R036	1-216-821-11	METAL CHIP	1K 5% 1/10W
Q295	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF	R051	1-215-892-11	METAL OXIDE	1K 5% 2W
Q300	6-551-696-01	TRANSISTOR	ISA1235AC1TP-1EF	R052	1-246-024-21	METAL CHIP	150 5% 1/2W
Q301	6-551-696-01	TRANSISTOR	ISA1235AC1TP-1EF	R062	1-216-825-11	METAL CHIP	2.2K 5% 1/10W (E4)
Q302	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF	R063	1-216-825-11	METAL CHIP	2.2K 5% 1/10W (E4)
Q303	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF	R077	1-216-829-11	METAL CHIP	4.7K 5% 1/10W
Q350	8-729-038-28	TRANSISTOR	RT1N441C-TP-1	R078	1-216-829-11	METAL CHIP	4.7K 5% 1/10W
Q351	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF	R079	1-216-834-11	METAL CHIP	12K 5% 1/10W
Q352	8-729-037-13	TRANSISTOR	KTA1271Y	R081	1-218-835-11	METAL CHIP	330 0.5% 1/10W
Q353	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF	R082	1-218-839-11	METAL CHIP	470 0.5% 1/10W
Q354	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF	R083	1-218-855-11	METAL CHIP	2.2K 0.5% 1/10W
Q360	8-729-032-94	TRANSISTOR	2SD1859TV2Q	R086	1-218-855-11	METAL CHIP	2.2K 0.5% 1/10W
Q400	6-551-276-01	TRANSISTOR	RT1N431C-TP-1	R090	1-218-835-11	METAL CHIP	330 0.5% 1/10W
Q500	8-729-027-26	TRANSISTOR	DTA114YKA-T146	R091	1-218-839-11	METAL CHIP	470 0.5% 1/10W
Q582	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF	R092	1-218-869-11	METAL CHIP	8.2K 0.5% 1/10W
Q600	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF	R093	1-216-864-11	SHORT CHIP	0
Q602	8-729-037-13	TRANSISTOR	KTA1271Y	R094	1-218-835-11	METAL CHIP	330 0.5% 1/10W
Q640	8-729-024-43	TRANSISTOR	2SA1365-T112-1EF	R095	1-218-839-11	METAL CHIP	470 0.5% 1/10W
Q641	8-729-024-43	TRANSISTOR	2SA1365-T112-1EF	R096	1-218-847-11	METAL CHIP	1K 0.5% 1/10W
Q643	8-729-047-62	TRANSISTOR	2SC3440-T12-1F	R097	1-218-851-11	METAL CHIP	1.5K 0.5% 1/10W
Q644	8-729-047-62	TRANSISTOR	2SC3440-T12-1F				
Q645	8-729-024-43	TRANSISTOR	2SA1365-T112-1EF				
Q646	8-729-024-43	TRANSISTOR	2SA1365-T112-1EF				
Q647	8-729-047-62	TRANSISTOR	2SC3440-T12-1F				
Q648	8-729-047-62	TRANSISTOR	2SC3440-T12-1F				

# HCD-GTR88

## MAIN

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>		<u>Remark</u>		<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>		<u>Remark</u>			
R099	1-216-801-11	METAL CHIP	22	5%	1/10W	R235	1-218-867-11	METAL CHIP	6.8K	0.5%	1/10W		
R103	1-216-838-11	METAL CHIP	27K	5%	1/10W	R236	1-218-867-11	METAL CHIP	6.8K	0.5%	1/10W		
R104	1-216-849-11	METAL CHIP	220K	5%	1/10W	R240	1-216-833-11	METAL CHIP	10K	5%	1/10W		
R105	1-216-833-11	METAL CHIP	10K	5%	1/10W	R241	1-216-833-11	METAL CHIP	10K	5%	1/10W		
					(E4)	R242	1-216-821-11	METAL CHIP	1K	5%	1/10W		
R117	1-216-835-11	METAL CHIP	15K	5%	1/10W	R243	1-216-841-11	METAL CHIP	47K	5%	1/10W		
R121	1-216-833-11	METAL CHIP	10K	5%	1/10W	R244	1-216-821-11	METAL CHIP	1K	5%	1/10W		
						R253	1-216-817-11	METAL CHIP	470	5%	1/10W		
R122	1-216-833-11	METAL CHIP	10K	5%	1/10W	R256	1-216-833-11	METAL CHIP	10K	5%	1/10W		
R127	1-216-819-11	METAL CHIP	680	5%	1/10W	R258	1-216-838-11	METAL CHIP	27K	5%	1/10W		
R128	1-216-835-11	METAL CHIP	15K	5%	1/10W	R270	1-216-832-11	METAL CHIP	8.2K	5%	1/10W		
R131	1-216-821-11	METAL CHIP	1K	5%	1/10W	R271	1-216-817-11	METAL CHIP	470	5%	1/10W		
R132	1-216-829-11	METAL CHIP	4.7K	5%	1/10W	R272	1-218-725-11	METAL CHIP	24K	0.5%	1/10W		
R133	1-216-829-11	METAL CHIP	4.7K	5%	1/10W	R273	1-218-331-11	METAL CHIP	51K	5%	1/10W		
R136	1-216-826-11	METAL CHIP	2.7K	5%	1/10W	R274	1-216-830-11	METAL CHIP	5.6K	5%	1/10W		
					(E4)	R275	1-216-841-11	METAL CHIP	47K	5%	1/10W		
R137	1-218-866-11	METAL CHIP	6.2K	0.5%	1/10W	R276	1-216-841-11	METAL CHIP	47K	5%	1/10W		
					(E4)	R277	1-216-839-11	METAL CHIP	33K	5%	1/10W		
R142	1-218-866-11	METAL CHIP	6.2K	0.5%	1/10W	R278	1-216-821-11	METAL CHIP	1K	5%	1/10W		
					(E4)	R279	1-216-821-11	METAL CHIP	1K	5%	1/10W		
R153	1-216-838-11	METAL CHIP	27K	5%	1/10W	R280	1-216-803-11	METAL CHIP	33	5%	1/10W		
R154	1-216-849-11	METAL CHIP	220K	5%	1/10W	R281	1-216-838-11	METAL CHIP	27K	5%	1/10W		
R155	1-216-833-11	METAL CHIP	10K	5%	1/10W	R283	1-216-845-11	METAL CHIP	100K	5%	1/10W		
					(E4)	R285	1-218-867-11	METAL CHIP	6.8K	0.5%	1/10W		
R177	1-216-819-11	METAL CHIP	680	5%	1/10W	R286	1-218-867-11	METAL CHIP	6.8K	0.5%	1/10W		
						R290	1-216-833-11	METAL CHIP	10K	5%	1/10W		
R178	1-216-835-11	METAL CHIP	15K	5%	1/10W	R291	1-216-833-11	METAL CHIP	10K	5%	1/10W		
R182	1-216-829-11	METAL CHIP	4.7K	5%	1/10W	R292	1-216-821-11	METAL CHIP	1K	5%	1/10W		
R183	1-216-829-11	METAL CHIP	4.7K	5%	1/10W	R293	1-216-841-11	METAL CHIP	47K	5%	1/10W		
R184	1-216-821-11	METAL CHIP	1K	5%	1/10W	R294	1-216-821-11	METAL CHIP	1K	5%	1/10W		
R186	1-216-826-11	METAL CHIP	2.7K	5%	1/10W			R295	1-216-853-11	METAL CHIP	470K	5%	1/10W
					(E4)			R296	1-216-825-11	METAL CHIP	2.2K	5%	1/10W
R187	1-218-866-11	METAL CHIP	6.2K	0.5%	1/10W			R298	1-216-821-11	METAL CHIP	1K	5%	1/10W
					(E4)			R299	1-216-821-11	METAL CHIP	1K	5%	1/10W
R188	1-216-833-11	METAL CHIP	10K	5%	1/10W	R300	1-216-817-11	METAL CHIP	470	5%	1/10W		
R190	1-216-857-11	METAL CHIP	1M	5%	1/10W	R301	1-216-817-11	METAL CHIP	470	5%	1/10W		
R192	1-218-866-11	METAL CHIP	6.2K	0.5%	1/10W			R302	1-216-825-11	METAL CHIP	2.2K	5%	1/10W
					(E4)			R303	1-216-819-11	METAL CHIP	680	5%	1/10W
R194	1-216-821-11	METAL CHIP	1K	5%	1/10W								
R196	1-216-833-11	METAL CHIP	10K	5%	1/10W	R304	1-216-841-11	METAL CHIP	47K	5%	1/10W		
R202	1-216-864-11	SHORT CHIP	0			R307	1-216-833-11	METAL CHIP	10K	5%	1/10W		
R203	1-216-817-11	METAL CHIP	470	5%	1/10W	R351	1-216-833-11	METAL CHIP	10K	5%	1/10W		
R204	1-216-845-11	METAL CHIP	100K	5%	1/10W	R352	1-216-837-11	METAL CHIP	22K	5%	1/10W		
R206	1-216-833-11	METAL CHIP	10K	5%	1/10W	R353	1-216-833-11	METAL CHIP	10K	5%	1/10W		
R208	1-216-838-11	METAL CHIP	27K	5%	1/10W	R354	1-216-833-11	METAL CHIP	10K	5%	1/10W		
R210	1-216-821-11	METAL CHIP	1K	5%	1/10W	R355	1-216-845-11	METAL CHIP	100K	5%	1/10W		
R211	1-216-844-11	METAL CHIP	82K	5%	1/10W	R356	1-216-845-11	METAL CHIP	100K	5%	1/10W		
R215	1-216-851-11	METAL CHIP	330K	5%	1/10W	R357	1-216-825-11	METAL CHIP	2.2K	5%	1/10W		
R216	1-216-809-11	METAL CHIP	100	5%	1/10W	R358	1-216-819-11	METAL CHIP	680	5%	1/10W		
R217	1-218-272-11	METAL CHIP	5.1K	5%	1/10W	R361	1-216-815-11	METAL CHIP	330	5%	1/10W		
R220	1-216-832-11	METAL CHIP	8.2K	5%	1/10W	R401	1-216-809-11	METAL CHIP	100	5%	1/10W		
R221	1-216-817-11	METAL CHIP	470	5%	1/10W	R402	1-216-809-11	METAL CHIP	100	5%	1/10W		
R222	1-218-725-11	METAL CHIP	24K	0.5%	1/10W	R404	1-216-809-11	METAL CHIP	100	5%	1/10W		
R223	1-218-331-11	METAL CHIP	51K	5%	1/10W	R405	1-216-821-11	METAL CHIP	1K	5%	1/10W		
R224	1-216-830-11	METAL CHIP	5.6K	5%	1/10W	R406	1-216-821-11	METAL CHIP	1K	5%	1/10W		
R225	1-216-841-11	METAL CHIP	47K	5%	1/10W	R407	1-216-821-11	METAL CHIP	1K	5%	1/10W		
R227	1-216-839-11	METAL CHIP	33K	5%	1/10W	R409	1-216-833-11	METAL CHIP	10K	5%	1/10W		
R228	1-216-821-11	METAL CHIP	1K	5%	1/10W	R410	1-219-570-11	METAL CHIP	10M	5%	1/10W		
R229	1-216-821-11	METAL CHIP	1K	5%	1/10W	R411	1-216-849-11	METAL CHIP	220K	5%	1/10W		
R231	1-216-838-11	METAL CHIP	27K	5%	1/10W	R413	1-216-857-11	METAL CHIP	1M	5%	1/10W		
R233	1-216-845-11	METAL CHIP	100K	5%	1/10W	R418	1-216-821-11	METAL CHIP	1K	5%	1/10W		

MAIN

Ref. No.	Part No.	Description		Remark	Ref. No.	Part No.	Description		Remark		
R419	1-216-821-11	METAL CHIP	1K	5%	1/10W	R582	1-216-821-11	METAL CHIP	1K	5%	1/10W
R421	1-216-821-11	METAL CHIP	1K	5%	1/10W	R585	1-216-835-11	METAL CHIP	15K	5%	1/10W
R422	1-216-821-11	METAL CHIP	1K	5%	1/10W	R587	1-216-833-11	METAL CHIP	10K	5%	1/10W
R429	1-216-833-11	METAL CHIP	10K	5%	1/10W	R589	1-216-835-11	METAL CHIP	15K	5%	1/10W
R430	1-216-833-11	METAL CHIP	10K	5%	1/10W	R593	1-216-834-11	METAL CHIP	12K	5%	1/10W
R434	1-216-809-11	METAL CHIP	100	5%	1/10W	R593	1-216-841-11	METAL CHIP	47K	5%	1/10W
R435	1-216-809-11	METAL CHIP	100	5%	1/10W	R593	1-218-867-11	METAL CHIP	6.8K	0.5%	1/10W
R436	1-216-809-11	METAL CHIP	100	5%	1/10W					(E4)	
R437	1-216-809-11	METAL CHIP	100	5%	1/10W	R597	1-216-835-11	METAL CHIP	15K	5%	1/10W
R438	1-216-809-11	METAL CHIP	100	5%	1/10W	R604	1-216-821-11	METAL CHIP	1K	5%	1/10W
R439	1-216-809-11	METAL CHIP	100	5%	1/10W	R606	1-216-837-11	METAL CHIP	22K	5%	1/10W
R444	1-216-809-11	METAL CHIP	100	5%	1/10W	R607	1-216-837-11	METAL CHIP	22K	5%	1/10W
R445	1-216-809-11	METAL CHIP	100	5%	1/10W	R608	1-216-828-11	METAL CHIP	3.9K	5%	1/10W
R446	1-216-809-11	METAL CHIP	100	5%	1/10W	R609	1-216-864-11	SHORT CHIP	0		
R447	1-216-809-11	METAL CHIP	100	5%	1/10W	R610	1-216-845-11	METAL CHIP	100K	5%	1/10W
R450	1-216-809-11	METAL CHIP	100	5%	1/10W	R612	1-216-833-11	METAL CHIP	10K	5%	1/10W
R451	1-216-809-11	METAL CHIP	100	5%	1/10W	R613	1-216-825-11	METAL CHIP	2.2K	5%	1/10W
R453	1-216-809-11	METAL CHIP	100	5%	1/10W	R614	1-216-817-11	METAL CHIP	470	5%	1/10W
R454	1-216-809-11	METAL CHIP	100	5%	1/10W	R615	1-216-833-11	METAL CHIP	10K	5%	1/10W
R460	1-216-809-11	METAL CHIP	100	5%	1/10W	R616	1-216-818-11	METAL CHIP	560	5%	1/10W
R465	1-216-829-11	METAL CHIP	4.7K	5%	1/10W	R617	1-216-825-11	METAL CHIP	2.2K	5%	1/10W
R467	1-216-809-11	METAL CHIP	100	5%	1/10W	R641	1-216-817-11	METAL CHIP	470	5%	1/10W
R471	1-216-845-11	METAL CHIP	100K	5%	1/10W	R642	1-216-841-11	METAL CHIP	47K	5%	1/10W
R472	1-216-809-11	METAL CHIP	100	5%	1/10W	R643	1-216-817-11	METAL CHIP	470	5%	1/10W
				(E4)	R644	1-216-841-11	METAL CHIP	47K	5%	1/10W	
R473	1-216-833-11	METAL CHIP	10K	5%	1/10W	R645	1-216-818-11	METAL CHIP	560	5%	1/10W
R474	1-216-809-11	METAL CHIP	100	5%	1/10W	R646	1-216-818-11	METAL CHIP	560	5%	1/10W
R475	1-216-809-11	METAL CHIP	100	5%	1/10W	R647	1-216-841-11	METAL CHIP	47K	5%	1/10W
R481	1-216-821-11	METAL CHIP	1K	5%	1/10W						
R485	1-216-817-11	METAL CHIP	470	5%	1/10W	R648	1-216-841-11	METAL CHIP	47K	5%	1/10W
R486	1-216-809-11	METAL CHIP	100	5%	1/10W	R649	1-216-817-11	METAL CHIP	470	5%	1/10W
R488	1-216-809-11	METAL CHIP	100	5%	1/10W	R650	1-216-841-11	METAL CHIP	47K	5%	1/10W
R489	1-216-817-11	METAL CHIP	470	5%	1/10W	R651	1-216-817-11	METAL CHIP	470	5%	1/10W
R490	1-216-809-11	METAL CHIP	100	5%	1/10W	R652	1-216-841-11	METAL CHIP	47K	5%	1/10W
R491	1-216-809-11	METAL CHIP	100	5%	1/10W						
R493	1-216-839-11	METAL CHIP	33K	5%	1/10W	R653	1-216-818-11	METAL CHIP	560	5%	1/10W
				(AUS)	R654	1-216-818-11	METAL CHIP	560	5%	1/10W	
R493	1-216-833-11	METAL CHIP	10K	5%	1/10W	R655	1-216-841-11	METAL CHIP	47K	5%	1/10W
				(E2, E51, MX, AR)	R656	1-216-841-11	METAL CHIP	47K	5%	1/10W	
R493	1-216-841-11	METAL CHIP	47K	5%	1/10W	R657	1-216-790-11	METAL CHIP	2.7	5%	1/10W
				(E4)							
R494	1-216-809-11	METAL CHIP	100	5%	1/10W	R658	1-216-790-11	METAL CHIP	2.7	5%	1/10W
R495	1-216-809-11	METAL CHIP	100	5%	1/10W	R659	1-216-790-11	METAL CHIP	2.7	5%	1/10W
R497	1-216-817-11	METAL CHIP	470	5%	1/10W	R662	1-216-839-11	METAL CHIP	33K	5%	1/10W
R500	1-216-809-11	METAL CHIP	100	5%	1/10W	R663	1-216-837-11	METAL CHIP	22K	5%	1/10W
R505	1-216-837-11	METAL CHIP	22K	5%	1/10W	R664	1-216-825-11	METAL CHIP	2.2K	5%	1/10W
R506	1-216-837-11	METAL CHIP	22K	5%	1/10W	R666	1-216-815-11	METAL CHIP	330	5%	1/10W
R507	1-216-837-11	METAL CHIP	22K	5%	1/10W	R683	1-216-822-11	METAL CHIP	1.2K	5%	1/10W
R518	1-216-837-11	METAL CHIP	22K	5%	1/10W						
R519	1-216-837-11	METAL CHIP	22K	5%	1/10W						
R520	1-216-833-11	METAL CHIP	10K	5%	1/10W						
				(E4)							
R521	1-216-837-11	METAL CHIP	22K	5%	1/10W					< VIBRATOR >	
R522	1-216-837-11	METAL CHIP	22K	5%	1/10W	X401	1-760-252-12	VIBRATOR, CRYSTAL (32.768kHz)			
R531	1-216-821-11	METAL CHIP	1K	5%	1/10W	X402	1-781-472-21	VIBRATOR, CERAMIC (8MHz)			
R542	1-216-864-11	SHORT CHIP	0							*****	
R543	1-216-833-11	METAL CHIP	10K	5%	1/10W						
R551	1-216-833-11	METAL CHIP	10K	5%	1/10W						
R565	1-216-827-11	METAL CHIP	3.3K	5%	1/10W						
R571	1-216-837-11	METAL CHIP	22K	5%	1/10W						
R581	1-216-835-11	METAL CHIP	15K	5%	1/10W						

MIC POWER AMP

POWER AMP	SUBTRANS
-----------	----------

Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Description			Remark	
D1306	6-501-817-01	DIODE	MA2J1110GLS0					< RELAY >				
D1307	6-500-334-01	DIODE	MC2836-T112-1				RY1300	1-755-653-11	RELAY			
D1310	6-501-817-01	DIODE	MA2J1110GLS0					< TERMINAL >				
		< IC >										
△ IC1300	6-713-787-01	IC STK412-750-E					TB1300	1-820-067-21	TERMINAL BOARD (SPEAKER)			
		< TRANSISTOR >					TB1301	1-820-067-21	(FRONT SPEAKER)			
								TERMINAL BOARD (SPEAKER)				
								(SATELLITE SPEAKER)				
Q1300	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF					< THERMISTOR >				
Q1301	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF				TH1301	1-804-045-11	THERMISTOR			
Q1302	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF					*****				
Q1303	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF					*****				
Q1304	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF					*****				
								SUBTRANS BOARD				
								*****				
Q1305	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF					< CAPACITOR >				
Q1306	6-551-696-01	TRANSISTOR	ISA1235AC1TP-1EF									
Q1307	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF				C1200	1-164-156-11	CERAMIC CHIP	0.1uF	25V	
Q1308	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF				C1201	1-164-156-11	CERAMIC CHIP	0.1uF	25V	
Q1309	8-729-027-38	TRANSISTOR	DTA144EKA-T146				C1203	1-126-942-61	ELECT	1000uF	20%	
		< RESISTOR >					C1204	1-126-963-11	ELECT	4.7uF	20%	
R1300	1-250-336-11	FUSIBLE	100	5%	1/2W		C1205	1-164-156-11	CERAMIC CHIP	0.1uF	25V	
R1301	1-250-336-11	FUSIBLE	100	5%	1/2W		C1206	1-164-156-11	CERAMIC CHIP	0.1uF	25V	
R1302	1-215-872-11	METAL OXIDE	3.3K	5%	1W			< CONNECTOR >				
R1303	1-215-872-11	METAL OXIDE	3.3K	5%	1W							
R1304	1-216-821-11	METAL CHIP	1K	5%	1/10W							
R1305	1-216-821-11	METAL CHIP	1K	5%	1/10W		* CN1200	1-793-660-11	PIN, CONNECTOR (PC BOARD) 3P			
R1306	1-216-845-11	METAL CHIP	100K	5%	1/10W		* CN1201	1-566-664-11	PIN, CONNECTOR (3.96mm PITCH) 4P			
R1307	1-216-845-11	METAL CHIP	100K	5%	1/10W						(E2, E51, E4)	
R1308	1-216-841-11	METAL CHIP	47K	5%	1/10W		* CN1202	1-568-226-11	PIN, CONNECTOR (3.96mm PITCH) 2P			
R1309	1-216-841-11	METAL CHIP	47K	5%	1/10W						(MX, AR, AUS)	
R1310	1-216-842-11	METAL CHIP	56K	5%	1/10W			< DIODE >				
R1311	1-216-842-11	METAL CHIP	56K	5%	1/10W							
R1312	1-216-821-11	METAL CHIP	1K	5%	1/10W		D1200	6-501-817-01	DIODE	MA2J1110GLS0		
R1313	1-216-821-11	METAL CHIP	1K	5%	1/10W		D1201	6-500-848-01	DIODE	MC2840-T112-1		
R1314	1-216-842-11	METAL CHIP	56K	5%	1/10W		D1202	6-500-848-01	DIODE	MC2840-T112-1		
R1315	1-216-843-11	METAL CHIP	68K	5%	1/10W		D1203	6-500-335-01	DIODE	MC2838-T112-1		
R1316	1-250-312-21	METAL CHIP	10	5%	1/2W			< TRANSFORMER >				
R1317	1-216-845-11	METAL CHIP	100K	5%	1/10W							
R1318	1-216-841-11	METAL CHIP	47K	5%	1/10W		△ PT1200	1-443-927-21	TRANSFORMER, POWER (SUB) (MX)			
R1319	1-216-837-11	METAL CHIP	22K	5%	1/10W		△ PT1200	1-445-875-11	POWER TRANSFORMER (SUB) (EXCEPT MX)			
R1320	1-250-312-21	METAL CHIP	10	5%	1/2W			< TRANSISTOR >				
R1324	1-217-637-55	FUSIBLE	1	5%	1/4W							
R1325	1-216-849-11	METAL CHIP	220K	5%	1/10W		Q1200	8-729-620-07	TRANSISTOR	2SC3052EF-T1-LEF		
R1326	1-216-849-11	METAL CHIP	220K	5%	1/10W			< RESISTOR >				
R1327	1-216-849-11	METAL CHIP	220K	5%	1/10W							
R1328	1-216-849-11	METAL CHIP	220K	5%	1/10W		R1201	1-216-819-11	METAL CHIP	680	5%	
R1329	1-216-820-11	METAL CHIP	820	5%	1/10W		R1202	1-216-825-11	METAL CHIP	2.2K	5%	
R1330	1-216-820-11	METAL CHIP	820	5%	1/10W						1/10W	
R1331	1-216-842-11	METAL CHIP	56K	5%	1/10W			< RELAY >				
R1332	1-216-842-11	METAL CHIP	56K	5%	1/10W							
R1333	1-216-836-11	METAL CHIP	18K	5%	1/10W		△ RY1200	1-755-334-11	RELAY, AC POWER			
R1334	1-216-845-11	METAL CHIP	100K	5%	1/10W			< SWITCH >				
R1335	1-216-845-11	METAL CHIP	100K	5%	1/10W							
R1337	1-216-829-11	METAL CHIP	4.7K	5%	1/10W		△ S1200	1-786-055-31	SELECTOR, VOLTAGE (E2, E51, E4)			
R1338	1-216-827-11	METAL CHIP	3.3K	5%	1/10W			*****				
R1339	1-216-840-11	METAL CHIP	39K	5%	1/10W							
R1344	1-216-839-11	METAL CHIP	33K	5%	1/10W							
R1345	1-216-821-11	METAL CHIP	1K	5%	1/10W							
R1346	1-234-798-11	ENCAPSULATED COMPONENT										
R1347	1-234-798-11	ENCAPSULATED COMPONENT										

## SUBWOOFER TC

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>			<u>Remark</u>	<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>			<u>Remark</u>									
***** SUBWOOFER BOARD *****																				
< CAPACITOR >																				
(EXCEPT MX)																				
C800	1-126-947-11	ELECT	47uF	20%	35V	R841	1-216-848-11	METAL CHIP	180K	5%	1/10W									
C801	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	R850	1-216-817-11	METAL CHIP	470	5%	1/10W									
C802	1-126-963-11	ELECT	4.7uF	20%	50V	R850	1-216-818-11	METAL CHIP	560	5%	1/10W									
C803	1-162-927-11	CERAMIC CHIP	100PF	5%	50V	R851	1-216-843-11	METAL CHIP	68K	5%	1/10W									
C808	1-162-915-11	CERAMIC CHIP	10PF	0.5PF	50V	R852	1-216-821-11	METAL CHIP	1K	5%	1/10W									
C825	1-128-576-11	ELECT	100uF	20%	63V	R858	1-216-843-11	METAL CHIP	68K	5%	1/10W									
C826	1-128-576-11	ELECT	100uF	20%	63V	R860	1-216-841-11	METAL CHIP	47K	5%	1/10W									
C846	1-115-339-11	CERAMIC CHIP	0.1uF	10%	50V	R880	1-250-312-21	METAL CHIP	10	5%	1/2W									
C847	1-115-339-11	CERAMIC CHIP	0.1uF	10%	50V	R888	1-220-893-11	METAL	0.22	10%	5W									
C850	1-126-947-11	ELECT	47uF	20%	35V	R889	1-216-825-11	METAL CHIP	2.2K	5%	1/10W									
C851	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	R890	1-216-837-11	METAL CHIP	22K	5%	1/10W									
C852	1-126-963-11	ELECT	4.7uF	20%	50V	R891	1-216-848-11	METAL CHIP	180K	5%	1/10W									
C853	1-162-927-11	CERAMIC CHIP	100PF	5%	50V	R893	1-216-864-11	SHORT CHIP	0											
C858	1-162-915-11	CERAMIC CHIP	10PF	0.5PF	50V	< RELAY >														
C875	1-128-557-11	ELECT	0.1uF	20%	100V	RY862	1-755-653-11	RELAY	< TERMINAL >											
C876	1-128-557-11	ELECT	0.1uF	20%	100V	TB801	1-820-067-21	TERMINAL BOARD (SPEAKER) (SUBWOOFER)	*****											
< CONNECTOR >																				
* CN803	1-564-510-11	PLUG, CONNECTOR 7P											TC BOARD (E4)							
CN804	1-778-227-41	CONNECTOR, BOARD TO BOARD 6P											*****							
< DIODE >																				
D800	6-500-335-01	DIODE MC2838-T112-1	C501	1-104-658-91	ELECT	100uF	20%	10V												
D811	6-501-817-01	DIODE MA2J1110GLS0	C502	1-104-658-91	ELECT	100uF	20%	10V												
< IC >																				
△ IC800	6-710-842-01	IC STK433-130-E	C503	1-162-966-11	CERAMIC CHIP	0.0022uF	10%	50V												
< JUMPER RESISTOR >																				
JR804	1-216-296-11	SHORT CHIP	0	C504	1-162-966-11	CERAMIC CHIP	0.0022uF	10%	50V											
JR811	1-216-864-11	SHORT CHIP	0	C505	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V											
< TRANSISTOR >																				
Q800	8-729-924-99	TRANSISTOR	2SC3722K-E	C506	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V											
Q850	8-729-924-99	TRANSISTOR	2SC3722K-E	C509	1-127-804-91	CERAMIC CHIP	100PF	1%	50V											
< RESISTOR >																				
R800	1-216-817-11	METAL CHIP	470	5%	1/10W	C510	1-127-804-91	CERAMIC CHIP	100PF	1%	50V									
R800	1-216-818-11	METAL CHIP	560	5%	1/10W	C511	1-162-960-11	CERAMIC CHIP	220PF	10%	50V									
(EXCEPT MX)																				
R804	1-217-637-55	FUSIBLE	1	5%	1/4W	C512	1-162-960-11	CERAMIC CHIP	220PF	10%	50V									
R808	1-216-843-11	METAL CHIP	68K	5%	1/10W	C513	1-126-160-11	ELECT	1uF	20%	50V									
R802	1-216-821-11	METAL CHIP	1K	5%	1/10W	C514	1-126-160-11	ELECT	1uF	20%	50V									
R804	1-217-637-55	FUSIBLE	1	5%	1/4W	C515	1-126-786-11	ELECT	47uF	20%	16V									
R808	1-216-843-11	METAL CHIP	68K	5%	1/10W	C516	1-126-947-11	ELECT	47uF	20%	35V									
R810	1-216-840-11	METAL CHIP	39K	5%	1/10W	C517	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V									
R812	1-216-864-11	SHORT CHIP	0	C519	1-162-962-11	CERAMIC CHIP	470PF	10%	50V											
R814	1-216-830-11	METAL CHIP	5.6K	5%	1/10W	C520	1-162-962-11	CERAMIC CHIP	470PF	10%	50V									
R827	1-250-336-11	FUSIBLE	100	5%	1/2W	C521	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V									
R828	1-250-336-11	FUSIBLE	100	5%	1/2W	C522	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V									
R830	1-250-312-21	METAL CHIP	10	5%	1/2W	C523	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V									
R838	1-220-893-11	METAL	0.22	10%	5W	C524	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V									
R839	1-216-825-11	METAL CHIP	2.2K	5%	1/10W	C525	1-162-923-11	CERAMIC CHIP	47PF	5%	50V									
R840	1-216-837-11	METAL CHIP	22K	5%	1/10W	C526	1-162-923-11	CERAMIC CHIP	47PF	5%	50V									
(MX)																				
R808	1-216-843-11	METAL CHIP	68K	5%	1/10W	C527	1-162-962-11	CERAMIC CHIP	470PF	10%	50V									
R810	1-216-840-11	METAL CHIP	39K	5%	1/10W	C528	1-162-962-11	CERAMIC CHIP	470PF	10%	50V									
R812	1-216-864-11	SHORT CHIP	0	C529	1-162-961-11	CERAMIC CHIP	330PF	10%	50V											
R814	1-216-830-11	METAL CHIP	5.6K	5%	1/10W	C530	1-162-961-11	CERAMIC CHIP	330PF	10%	50V									
R827	1-250-336-11	FUSIBLE	100	5%	1/2W	C531	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V									
R828	1-250-336-11	FUSIBLE	100	5%	1/2W	C532	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V									
R830	1-250-312-21	METAL CHIP	10	5%	1/2W	C533	1-162-966-11	CERAMIC CHIP	0.0022uF	10%	50V									
R838	1-220-893-11	METAL	0.22	10%	5W	C534	1-162-966-11	CERAMIC CHIP	0.0022uF	10%	50V									
R839	1-216-825-11	METAL CHIP	2.2K	5%	1/10W	C535	1-162-966-11	CERAMIC CHIP	0.0022uF	10%	50V									
R840	1-216-837-11	METAL CHIP	22K	5%	1/10W	C536	1-162-966-11	CERAMIC CHIP	0.0022uF	10%	50V									

Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Description			Remark
C537	1-162-966-11	CERAMIC CHIP	0.0022uF	10%	50V	R513	1-216-845-11	METAL CHIP	100K	5%	1/10W
C538	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	R514	1-216-845-11	METAL CHIP	100K	5%	1/10W
C539	1-115-156-11	CERAMIC CHIP	1uF		10V	R515	1-216-864-11	SHORT CHIP	0		
C540	1-130-479-91	MYLAR	0.0047uF	5%	50V	R516	1-216-864-11	SHORT CHIP	0		
C542	1-126-796-11	ELECT	22uF	20%	50V	R517	1-216-821-11	METAL CHIP	1K	5%	1/10W
C543	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	R518	1-216-821-11	METAL CHIP	1K	5%	1/10W
C545	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V	R519	1-216-841-11	METAL CHIP	47K	5%	1/10W
C546	1-100-597-91	CERAMIC CHIP	0.1uF	10%	25V	R520	1-216-841-11	METAL CHIP	47K	5%	1/10W
C548	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	R521	1-216-841-11	METAL CHIP	47K	5%	1/10W
C549	1-164-156-11	CERAMIC CHIP	0.1uF		25V	R522	1-216-841-11	METAL CHIP	47K	5%	1/10W
< CONNECTOR >											
* CN501	1-564-710-11	PIN, CONNECTOR (SMALL TYPE) 8P				R526	1-216-851-11	METAL CHIP	330K	5%	1/10W
CN502	1-784-731-11	CONNECTOR, FFC 9P				R527	1-216-851-11	METAL CHIP	330K	5%	1/10W
< IC >											
IC501	8-759-100-96	IC	uPC4558G2			R528	1-216-851-11	METAL CHIP	330K	5%	1/10W
IC502	8-759-100-96	IC	uPC4558G2			R529	1-216-825-11	METAL CHIP	2.2K	5%	1/10W
< JUMPER RESISTOR >											
JR501	1-216-864-11	SHORT CHIP	0			R530	1-216-825-11	METAL CHIP	2.2K	5%	1/10W
JR502	1-216-864-11	SHORT CHIP	0			R531	1-216-832-11	METAL CHIP	8.2K	5%	1/10W
JR503	1-216-864-11	SHORT CHIP	0			R532	1-216-832-11	METAL CHIP	8.2K	5%	1/10W
JR504	1-216-295-91	SHORT CHIP	0			R533	1-216-837-11	METAL CHIP	22K	5%	1/10W
JR505	1-216-295-91	SHORT CHIP	0			R534	1-216-835-11	METAL CHIP	15K	5%	1/10W
JR506	1-216-296-11	SHORT CHIP	0			R535	1-216-829-11	METAL CHIP	4.7K	5%	1/10W
JR507	1-216-296-11	SHORT CHIP	0			R536	1-216-829-11	METAL CHIP	4.7K	5%	1/10W
JR508	1-216-296-11	SHORT CHIP	0			R537	1-216-833-11	METAL CHIP	10K	5%	1/10W
JR509	1-216-296-11	SHORT CHIP	0			R538	1-216-833-11	METAL CHIP	10K	5%	1/10W
JR510	1-216-295-91	SHORT CHIP	0			R539	1-216-793-11	METAL CHIP	4.7	5%	1/10W
JR511	1-216-296-11	SHORT CHIP	0			R540	1-216-805-11	METAL CHIP	47	5%	1/10W
JR512	1-216-296-11	SHORT CHIP	0			R541	1-216-805-11	METAL CHIP	47	5%	1/10W
JR513	1-216-296-11	SHORT CHIP	0			R543	1-216-813-11	METAL CHIP	220	5%	1/10W
JR514	1-216-296-11	SHORT CHIP	0			R544	1-216-813-11	METAL CHIP	220	5%	1/10W
JR515	1-216-296-11	SHORT CHIP	0			R545	1-216-817-11	METAL CHIP	470	5%	1/10W
JR516	1-216-296-11	SHORT CHIP	0			R546	1-216-817-11	METAL CHIP	470	5%	1/10W
< SWITCH >											
JR517	1-216-296-11	SHORT CHIP	0			S501	1-762-369-11	SWITCH, SLIDE (REC/PB)			
JR518	1-216-296-11	SHORT CHIP	0			*****					
< COIL >											
L501	1-456-094-11	TRANSFORMER, BIAS OSCILLATION				*****					
< TRANSISTOR >											
Q501	8-729-119-78	TRANSISTOR	2SC2785-HFE			C1250	1-164-156-11	CERAMIC CHIP	0.1uF		25V
Q502	8-729-119-78	TRANSISTOR	2SC2785-HFE			C1251	1-164-156-11	CERAMIC CHIP	0.1uF		25V
< RESISTOR >											
R501	1-216-825-11	METAL CHIP	2.2K	5%	1/10W	C1252	1-126-964-11	ELECT	10uF	20%	50V
R502	1-216-825-11	METAL CHIP	2.2K	5%	1/10W	C1253	1-128-553-11	ELECT	220uF	20%	63V
R503	1-216-825-11	METAL CHIP	2.2K	5%	1/10W	C1254	1-126-968-11	ELECT	100uF	20%	50V
R504	1-216-825-11	METAL CHIP	2.2K	5%	1/10W	< CONNECTOR >					
R505	1-216-834-11	METAL CHIP	12K	5%	1/10W	CN1250	1-564-528-11	PLUG, CONNECTOR 13P			
R506	1-216-834-11	METAL CHIP	12K	5%	1/10W	< DIODE >					
R507	1-216-850-11	METAL CHIP	270K	5%	1/10W	D1250	6-500-522-21	DIODE	10EDB40-TB3		
R508	1-216-850-11	METAL CHIP	270K	5%	1/10W	D1252	6-501-796-01	DIODE	MAZ8330GMLS0		
R509	1-216-814-11	METAL CHIP	270	5%	1/10W	< FUSE >					
R510	1-216-814-11	METAL CHIP	270	5%	1/10W	△ F1254	1-523-080-11	FUSE	6.3A 250V		
R511	1-216-845-11	METAL CHIP	100K	5%	1/10W	△ F1255	1-523-084-11	FUSE	2A 250V		
R512	1-216-845-11	METAL CHIP	100K	5%	1/10W						

# HCD-GTR88

**TRANS** **USB** **VOL**

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>			<u>Remark</u>		<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>			<u>Remark</u>						
< HOLDER, FUSE >												< RESISTOR >						
FH1250	1-533-217-41	HOLDER, FUSE					R1001	1-216-817-11	METAL CHIP	470	5%	1/10W						
FH1251	1-533-217-41	HOLDER, FUSE					R1002	1-216-817-11	METAL CHIP	470	5%	1/10W						
FH1252	1-533-217-41	HOLDER, FUSE					R1004	1-216-823-11	METAL CHIP	1.5K	5%	1/10W						
FH1253	1-533-217-41	HOLDER, FUSE					R1005	1-216-823-11	METAL CHIP	1.5K	5%	1/10W						
FH1254	1-533-217-41	HOLDER, FUSE					R1008	1-216-817-11	METAL CHIP	470	5%	1/10W						
FH1255	1-533-217-41	HOLDER, FUSE					R1009	1-216-817-11	METAL CHIP	470	5%	1/10W						
FH1256	1-533-217-41	HOLDER, FUSE					*****											
FH1257	1-533-217-41	HOLDER, FUSE																
< TRANSISTOR >												VOL BOARD						
*****												*****						
Q1250	8-729-048-66	TRANSISTOR	2SB1238-PQR-TV2				< CAPACITOR >											
< RESISTOR >												C1301		1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V
R1250	1-216-821-11	METAL CHIP	1K	5%	1/10W		< RESISTOR >											
R1252	1-216-833-11	METAL CHIP	10K	5%	1/10W		R1302	1-216-833-11	METAL CHIP	10K	5%	1/10W						
*****													R1303	1-216-835-11	METAL CHIP	15K	5%	1/10W
USB BOARD													R1304	1-216-837-11	METAL CHIP	22K	5%	1/10W
*****													< SWITCH >					
< CAPACITOR >													S1301	1-487-171-11	ROTARY ENCODER (MASTER VOLUME)			
C1002	1-165-989-11	CERAMIC CHIP	10uF	10%	6.3V		S1302	1-786-289-31	SWITCH, DETECTION (DETECTION SWITCH)					*****				
C1003	1-126-176-11	ELECT	220uF	20%	10V		< RESISTOR >											
C1004	1-164-156-11	CERAMIC CHIP	0.1uF		25V		R1001	1-216-817-11	METAL CHIP	10K	5%	1/10W						
C1005	1-165-989-11	CERAMIC CHIP	10uF	10%	6.3V		R1002	1-216-833-11	METAL CHIP	10K	5%	1/10W						
C1006	1-126-176-11	ELECT	220uF	20%	10V		R1003	1-216-835-11	METAL CHIP	15K	5%	1/10W						
*****													R1004	1-216-837-11	METAL CHIP	22K	5%	1/10W
USB BOARD													< SWITCH >					
*****													S1301	1-487-171-11	ROTARY ENCODER (MASTER VOLUME)			
C1007	1-164-156-11	CERAMIC CHIP	0.1uF		25V		S1302	1-786-289-31	SWITCH, DETECTION (DETECTION SWITCH)					*****				
C1008	1-164-156-11	CERAMIC CHIP	0.1uF		25V		59	1-797-575-11	DECK, MECHANICAL (E4)					< CONNECTOR >				
C1009	1-164-156-11	CERAMIC CHIP	0.1uF		25V		103	1-824-954-11	FLAT FLEXIBLE CABLE FM0-8					C1007				
C1010	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V		104	1-838-099-11	FLEXIBLE FLAT CABLE (7 CORE)					C1008				
C1011	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V		105	1-828-976-11	WIRE (FLAT TYPE) (13 CORE)					C1009				
C1012	1-162-910-11	CERAMIC CHIP	5PF	0.25PF	50V		155	1-829-023-11	WIRE (FLAT TYPE) (23 CORE)					C1010				
C1013	1-162-910-11	CERAMIC CHIP	5PF	0.25PF	50V		< CONNECTOR >											
< CONNECTOR >													156	1-823-669-11	WIRE (FLAT TYPE) (11 CORE)			
< CONNECTOR >													251	1-828-952-11	WIRE (FLAT TYPE) (9 CORE)			
< CONNECTOR >													252	1-457-369-12	CORE, FERRITE			
< CONNECTOR >													255	1-693-778-31	TUNER (FM/AM) (EXCEPT AUS)			
< CONNECTOR >													255	1-693-778-22	TUNER (FM/AM) (AUS)			
CN1000	1-819-866-11	CONNECTOR, USB (A)					< DIODE >											
CN1001	1-819-866-11	CONNECTOR, USB (A)					△ 257	1-777-071-83	CORD, POWER (E2, E51, E4)					< DIODE >				
< DIODE >							△ 257	1-835-068-21	CORD, POWER (AUS)					CN1000				
< DIODE >							△ 257	1-837-312-11	CORD, POWER-SUPPLY (AR)					CN1001				
< DIODE >							△ 257	1-837-344-11	CORD, POWER-SUPPLY (MX)					CN1002				
< DIODE >							△ 258	1-569-008-21	ADAPTOR, CONVERSION (E2, E51, E4)					CN1003				
< DIODE >							401	1-840-387-31	MECHANICAL, CD					CN1004				
< DIODE >							△ 405	8-820-322-04	DEVICE, OPTICAL KHM-313CAB/C2NP (including sled motor, spindle motor)					CN1005				
< DIODE >							407	1-828-773-51	WIRE (FLAT TYPE) (24 CORE)					CN1006				
< DIODE >							△ F1250	1-533-949-33	FUSE, T8AL 250V					CN1007				
< DIODE >							△ F1251	1-533-949-33	FUSE, T8AL 250V					CN1008				
< DIODE >							△ F1252	1-533-949-33	FUSE, T8AL 250V					CN1009				
< DIODE >							△ F1253	1-533-949-33	FUSE, T8AL 250V					CN1010				
< DIODE >							△ M101	1-787-344-11	FAN, DC					CN1011				
< DIODE >							△ PT1250	1-445-825-11	POWER TRANSFORMER (MX)					CN1012				
< DIODE >							△ PT1250	1-445-826-11	POWER TRANSFORMER (EXCEPT MX)					CN1013				
< JUMPER RESISTOR >							< JUMPER RESISTOR >											
JR102	1-216-296-11	SHORT CHIP	0				S1301	1-487-171-11	ROTARY ENCODER					< JUMPER RESISTOR >				
JR103	1-216-296-11	SHORT CHIP	0				< JUMPER RESISTOR >											

## REVISION HISTORY

Checking the version allows you to jump to the revised page.

Also, clicking the version at the top of the revised page allows you to jump to the next revised page.