

AN1456 APPLICATION NOTE STA304 + STA500 DIGITAL AUDIO PROCESSOR EVALUATION BOARD OPERATING MANUAL

by Luca Molinari

1 EVALUATION BOARD

The STA304 Digital Audio Processor is a single chip device implementing end to end digital solution for audio application. In conjunction with STA500 Power Bridge it gives the full digital DSP-to-Power high quality chain with no need for Digital-to Analog converters.

The STA304 Evaluation kit is an example for a general application involving all the STA304 and STA500 capabilities, which gives the possibility to evaluate the system performances.

The evaluation kit consists of two boards, and control software. In the first board an STA304 and three STA500 are available, while the second is used to connect the main board to the PC. The control software allows then to control all the evaluation board capabilities from a simple visual interface.

1.1 LPT Interface (LPT300)

In order to allow proper communication between the 3.3V powered (digital) evaluation board and a standard LPT interface the STA304 evaluation kit includes also the LPT interface board (LPT300) shown in Figure 1. Basically the interface will perform a signal level translation between 3.3V and 5V in both directions.

The LPT300 interface take the supply (both 3.3V and 5V) from pins 17 and 18 of the connector J2 (see Figure 2), so no regulators are on board. There is the possibility to have also the regulator on board (U3 and U4), but in that case the pins 17 and 18 should be disconnected from the STA304 evaluation board. In Figure 2 the components that are not needed for LPT300 (such as regulators) are drawn in dashed lines.

IMPORTANT: the LPT300 interface can have some problems if the PC LPT port is configured as "bi-directional". In order to perform a quick test, after the LPT300 is connected to the STA304 board, switch on the supply and try the "Test procedure" (see the SETUP section). If the test doesn't succeed, try to check the PC parallel port settings: most PC in fact, can configure their LPT interface in different modes (SPP/EPP/ECP) and it could happen that some of those configurations are not well suited to control our evaluation kit.



Figure 1. LPT300 Interface Layout

January 2002





1.2 STA304 Evaluation Board

The STA304 evaluation board layout is shown in Figure 3.

The board has one SPDIF input (differential, electrical single ended, and optical), and two serial inputs. Three serial output are available, as well as five analog power outputs.

AC97 signals are available on connector J2 for an AC97 application (an AC97 external controller is needed).

Figure 3. STA304 eval. board layout



Three power stages (STA500) are mounted on board. The three devices take the analog supply from the terminal J1 (10V up to 35V), as well as the digital supply from the IC6 regulator.

IC3 and IC4 are configured to drive 8 ohm load (up to 30 W) on LEFT,RIGHT,S-LEFT,S-RIGHT, while IC1 is configured to drive 4 ohm load (up to 60 W) on LFE.

Some board behaviours are selectable from the Jumper and the switch on board, read carefully the "setup" section to avoid board damages.

Before using the STA304 demo board, the jumper J4 and J5 must be shorted. This jumper could be used to perform current measurement for STA304; in fact, they are in series to all the digital (J4) and the analog (J5) STA304 supply.

In case of STA500 damage, it is possible to break the supply to the damaged device using the relative jumper on the lower side of the board (near J1). Be sure that all the jumpers should be shorted if you want to use all the three power chip.

6 CHANNELS APPLICATION SUGGESTIONS

For the 6 channels applications, like DTS and AC3 it is mandatory to use two STA304.

In order to obtain the best results in terms of Audio Quality, we suggest to drive each STA50X with two PWM signals coming from a single STA304, otherwise some overlap of the PWM frames could generate undesired noise.

One possible configuration is:

Left / Right / Surround L / Surround R from the first STA304, CENTRE and LFE from the second one.

If STA50X in mono configuration is used for LFE (4 Ω application), than this LFE can be fed from any of the two STA304 because no crosstalk is present.



Figure 4. For theSTA304 evaluation board schematic

1.3 Setup and configuration

Before connecting the LPT300 and STA304 boards, check the jumper configuration:

The SW3 switch should be configured in this way:

- AC97 "ON" (switch 1)
- TEST_MODE "OFF" (switch 2)
- SA "OFF" (switch 3)
- PWDN "ON" (switch 4)

It is mandatory that the second switch is OFF, otherwise the STA304 is set to TEST MODE.

To avoid board damages the switch 1 and 4 should not be OFF when the LPT interface is connected. The second switch set the SA pin, so the I2C address can be changed. Up to now the demo board software can use only the seven bit address 0x1E (011110), so SA should be OFF.

Now the LPT300 interface and the STA304 demo board could be plugged together (BE CAREFUL, See Figure 5 for the plug).

Connect the PC parallel port to the LPT board using a parallel cable, and turn on the board supply.

Run STA304.exe on the PC, and select the Register page. Push the "RESET" button. In this condition the board should waste about 150-200mA.

Try now the "TEST" button, the software should read the first four, and the last four registers via I2C. If the values read are equal to the default the "Pass" message should appear, and the I2C interface is working.

If the test fail, try first of all to check the PC configuration. Try to change the parallel port configuration (EPP, ECP, etc.) and retry the test procedure starting from the RESET.

If the test is still fail, check the supply on the LPT interface, and on the STA304 demo board. Try to check also if the I2C signals (SCL, SDA) are moving while the TEST button is pressed. If SDA or SCL are not moving, maybe the LPT interface could be damaged.

Figure 5.



To select the SPDIF input way, the switch SW2 must be configured:

SW2 config.	Selected Interface
2-4-6-8	Electrical Professional
1-3-6-8	Electrical consumer
1-3-5-7	Optical

The numbers in the first column mean that a slider in the SW2 switch must be put in that position: for example 2-4-6-8 means that a slider must be in position 2, an other in position 4, an other in position 6, and the last in position 8.

When the Electrical Professional interface is selected, it is mandatory that the STA304 be configured as SPDIF

Á7/

Analog (I/O Page in the control panel). For the other interfaces, both Analog and digital could be used depending on input SPDIF levels. SPDIF digital could be used only if the RXP signal is in the range 0.2*VDD for ViL, and 0.8*VDD for ViH. SPDIF Analog could be used if the input SPDIF signal is above 400 mV peak to peak.

1.4 DDX Output

To activate the five DDX outputs the following procedure must be used:

- Select the input interface (the presets 1, 2, 3 could be used) from I/O Page;
- Select ST Table in Main Page;
- Remove the mute in the Main Page (*);
- Remove the DDX Reset in Main Page;
- Push Turn ON in Main Page.

At this point Sound should exit from the STA500.

(*) To avoid potential malfunctionings, it is recommended to remove the DDX mute only when both SRC and SPDIF are locked, i.e.: - If SPDIF is used, the first two bits of 77h address must be: bit 0 = 0, bit 1 = 0.

- If I2S is used, the first two bits of 77h address must be bit 0 = 0, bit 1 = don't care because it is referred to SPDIF.

2 CONTROL SOFTWARE

In order to control and evaluate the STA304 board a dedicated control panel has been developed. It runs on Win95/98 operating system and allows complete DSP control (volume, mute, tone, etc.), full Serial and SPDIF configuration, and demo board status monitoring (thermal warning, SPDIF and sample rate converter lock).

2.1 Main Page

A7/

— Volume I	Controls	Power Status Termal Warn. 1	
Volume R) dB Termal Warn. 2 () dB Termal Warn. 1 EE (
Volume SR		DdB Power Down	2
Volume LFE		DdB STA304 Status)
Bass Trable	J 1;	2 dB SPDIF Lock	ŏ
Left/Right Lock	Mute 🗖 DDX Res	et Presets 1 2 3 4 5	• 4
DSP bypass	DDX®Zero detect 🗖		os
Side Firing	DDX® table C ST	Apogee Commands	
Static EQ 🛛 🗍 SRC Bypass 🗍	SRC Th. Inactive	Reset 6	5

 The "Controls" section groups the volume, mute and tone controls for the STA304 demo board. There is a master mute that automatically check all the mute controls, and a Left/Right Lock that link together L-R SL-SR and CNT-LFE volume sliders. The range for the volume sliders depends on the full compliant bit in reg.

5Ah (see I/O Page) as described in the datasheet.

- 2) In this section some configuration bits are grouped (see the registers on data sheet for more info).
- 3) The section 3 groups the status 'led' for the board. There are 3 thermal warning (red if a STA500 goes in over heat), and two lock led for the Sample Rate Converter (SRC) and for the SPDIF. When a thermal warning is detected, the corresponding STA500 channels will be automatically muted to avoid the part destruction (in this case a by hand power off should be suggested). All the led are updated every 300 ms.
- 4) Some default control presets are already present in those 6 memories. To store the current control position just press down one of those buttons until it's automatically released. The presets buttons store and restore not only the volume, the tone and the mute settings, but the all registers that define the fundamental behaviour of STA304 demo board, such as if using SPDIF or I2S, the DDX table, etc. (registers 0x02;0x03;0x08;0x09;0x26;0x27;0x36:0x39;0x5A:0x77). As soon as the software is started, in the memory M1,M4,M5 and M6 are stored the default STA304 settings (i.e. the RESET values), while in the memory M2 there are the "SPDIF differential" settings, and finally in the memory M3 there are the "SPDIF digital".
- 5) Use this check-box to globally enable or disable the ToolTip function.
- 6) The "Turn off/on" button is used to put in power down or resume from the power down the STA500, while the "Standby/Resume" button put (resume) the STA304 in (from) powerdown, leaving the I2C and AC97 interface alive.

When entering in this page, all the controls are updated reading the STA304 registers.

2.2 I/O Page

Alignement 0 Alignement 0 Alignement 0 Master MSB First 5 Master 3 SPDIF Control Digital Input 5	AC97 Control	Bit Clock Polarity LOW LR Clock Polarity LOW
Alignement II II Master I MSB First I Double Buffer I 3 – SPDIF Control Auto NoAudio I Digital Input	- Serial Control Bit Clock Polarity LOW • LR Clock Polarity LOW •	Alignement 0 💽 Master 🗖 MSB First 🗖
	Alignement 10 Master MSB First Double Buffer SPDIF Control Auto NoAudio Digital Input	

In this page, all the input/output interfaces can be configured.

- 1) This 3 radio buttons are used to select from the 3 input interfaces supported by the STA304.
- 2) Regarding AC97, the software controls only the full compliant bit (if checked the STA304 works in full compliant mode as described in the datasheet).

Á7/

- 3) The Serial interface has different configurations. Choosing "Bit Clock Polarity" and "LR Clock Polarity", the bit and word clock polarity can be changed; the 'Alignment' field changes the data alignment respect to the word clock, and the number of active bit clock edges (see DAP input Stage section in the datasheet).
- 4) If 'Digital Input' is checked, the internal SPDIF trigger is bypassed, and only the RXP signal is used by STA304. In this configuration the input signal range is 0.2*VDD for ViL and 0.8*VDD for ViH. Otherwise RXP and RXN pass through a Differential schmitt trigger, and the signal should follow the AES3 specifications.
- 5) The output serial interface is configured in the same way of the input one (see I2S Output Interface section in the datasheet).

When entering in this page, all the controls are updated reading the STA304 registers.

2.3 Download Page

STA304 Control Panel Main 1/0 Settings Coefficient Handling Register 1/0 About
Load/Save
Filename <none> Load Save Download Read</none>
1
Coefficient Value LR00 00000 LR01 00001 LR02 00002 LR03 00003 LR04 00004 LR10 00005 LR11 00006
LR12 00007 LR13 00008 LR14 00009
STA204 Control Panel © STMicroelectronics
STASD4 Control Patier © STIVICroelectronics

Using this page it is possible to read and download the coefficients in STA304. It is possible also to save and load from file the values.

- Load: pushing the load button a load dialog will appear, and selecting a coefficients file the table 2 will be updated with the new values read.
- Save: pushing the save button a save dialog will appear, selecting a file name the coefficient table will be saved.
- Download: pushing this button the current table value will be stored in STA304.
- Read: pushing this button all the coefficient values will be read from STA304, and the table updated with the read values.

It is possible to write a comment for the coefficients file (in box 1), and it will be saved during the save procedure, and loaded in the load procedure.



A coefficients file is made of two comment lines at the top (comments begin with '#'), and a list of pair addressvalue for every coefficient. Note that is not mandatory to put all the coefficients in the file, but only the needed coefficient can be put. The numeric format for address and values can be either decimal or hexadecimal (ex. 0x1A). To have an example, the suggestion is to try to save the current coefficients, and to take a look to the saved file.

```
The C code linked to the Download button is:
```

```
BOOL DownloadPage::DownloadCoeff()
ł
      BOOL result=TRUE;
      char elem[8];
      int val;
      for(int i=0;i<NCOEF;++i)</pre>
      {
             m_coeff_list.GetItemText(i,1,elem,7);
             sscanf(elem,"%x",&val);
             result = result && WriteByte(0x78,(val & 0x0ff00)>>8);
            result = result && WriteByte(0x79,(val & 0x000ff)>>0);
             result = result && WriteByte(0x7A,(i+0x40));
             result = result && WriteByte(0x7B,0x0f & ((val & 0xf0000)>>16));
      }
      return(result);
}
```

The whole coefficients table is parsed with the "for(int i..." loop. A coefficient is written using the procedure described in Chapter 10 of the datasheet.

Regarding the read button, the code is:

```
void DownloadPage::OnCoeffRead()
{
      // TODO: Add your control notification handler code here
      int add, coe;
      char st[6];
      unsigned char dataL, dataM, dataH;
      for(add=0;add<NCOEF;++add)</pre>
             WriteByte(Coefficent_1H_ADD,(unsigned char)add+0x40);
             WriteByte(Coefficent_1L_ADD,(1<<7));</pre>
             ReadByte(Coefficent_0H_ADD,&dataM);
             ReadByte(Coefficent_0L_ADD,&dataL);
             ReadByte(Coefficent_1L_ADD,&dataH);
             dataH&=0xF;
             coe=(unsigned int)dataL+((unsigned int)dataM *256)+
                 ((unsigned int)dataH *256*256);
             sprintf(st, "%05x", coe);
             m_coeff_list.SetItemText(add,1,st);
      }
}
```

In this case all the coefficients are read, and stored in the table m_coeff_list.

The code above is just to show the read/write coefficient procedure, is not intended to show a real application code. Every application could have different code.

Á7/

2.4 Register Page



- 1 Using the controls in this section it's possible to manually access all the device control/configuration registers. Selecting a register in the list box 'Register Name', its value is automatically read. A register address can be inserted directly in the 'Address' edit box, but in this case only when the read button is pressed the register content is read. To write a register value, first select the register or insert its address in the edit box, then write the new value in the 'Data' edit box, finally press the 'Write' button.
- 2) To find the LPT port address, just use the 'Autofind' button. Typically there should be no need to use it, since the software automatically detects the parallel port address every time you run it. To change the I2C device address, the I2C box should be used. When the SA pin is hold to gnd (using SW3 switch on the demo board) ADD0 must be used, otherwise if SA is tie to Vdd ADD1 must be selected.
- 3) To put the STA304 in HW power down (all clocks off), or to perform an HW reset, this two button can be used. The HW reset will initialise all the device registers with their default values. To resume an HW powerdown the HW reset is mandatory.
- 4) In order to check the I2C connection and, basically, the correct setup of the evaluation kit a 'Test' button has been included in this page. It just read the first four and the last four registers of STA304, and compares theirs values with the default ones. This test must be done, obviously, after the 'Reset' button was pressed, and before any change in the 8 checked registers.

3 CAUTIONS

- Leaving an STA500 output without load while this channel is playing some signal could damage the device.
- Switch on the STA500 supply only if the STA304 is working and the button in 6 in the main page displays "Turn ON".
- Be sure that ST table is selected before switch on the three STA500

4 RELIABLE CIRCUIT DESIGN

Power Supply Decoupling

Minimize inductance loop area for SMD ceramic bypass capacitors configured to pins VCC1, VCC2, VCCSign, Vss, Vdd, and Ibias on STA500.

Poor decoupling on VCC1,2 and VCCSign could generate catastrophic failures on STA500 (especially in mono configuration) during continuous full power functioning. In these conditions the devices fail to prior activating thermal warning.

Power Routing

Provide star configuration power routing to each STA500 on a multichannel amplifier. Minimize inductance loop area between each STA500 and its respective bulk bypass capacitor.

Snubber Circuits

Locate the snubber circuits (C4+R3, C14+R8, C27+R12, C39+R17) as close as pratical between the outputs of the STA500.

Output Routing

- 1. Inductor Placement: maintain a minimum physical separation of one inductor's diameter, particularly between inductors of different channels.
- 2. Output traces: balance the impedance of traces in the output circuit so as to maintain source matching. Match pcb traces on each output circuit to within 10 milliohms.

Information furnished is believed to be accurate and reliable. However, STMicroelectronics assumes no responsibility for the consequences of use of such information nor for any infringement of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under any patent or patent rights of STMicroelectronics. Specifications mentioned in this publication are subject to change without notice. This publication supersedes and replaces all information previously supplied. STMicroelectronics products are not authorized for use as critical components in life support devices or systems without express written approval of STMicroelectronics.

STMicroelectronics GROUP OF COMPANIES

Australia - Brazil - Canada - China - Finland - France - Germany - Hong Kong - India - Israel - Italy - Japan -Malaysia - Malta - Morocco -Singapore - Spain - Sweden - Switzerland - United Kingdom - United States. http://www.st.com