

#### **General Description**

The MAX8576 evaluation kit (EV kit) is a fully assembled and tested circuit board that evaluates the MAX8576 and MAX8578 hysteretic, synchronous step-down DC-DC converters. The MAX8576 circuit generates a 1.8V output voltage at load currents up to 12A from a 10.8V to 13.2V input voltage range. The MAX8578 circuit uses an all-ceramic capacitor solution to generate a 1.8V output voltage at load currents up to 5A from a 10.8V to 13.2V input voltage with VCC supply from an additional 4.5V to 5.5V supply. The MAX8576 circuit switches at approximately 300kHz, and the MAX8578 circuit switches at approximately 500kHz. Both devices have up to 93% efficiency with the supplied components. The MAX8576 EV kit also evaluates the MAX8577 and MAX8579. To evaluate the MAX8577 or MAX8579, order a free sample along with this EV kit.

#### **Features**

- ♦ 10.8V to 13.2V Supply Voltage Range with 4.5V to 5.5V Vcc Supply Voltage Range
- **♦ 1.2% Accurate Over Temperature**
- **♦ Adjustable Output Voltage Down to 0.6V**
- ♦ 300kHz and 500kHz Switching Frequency
- ♦ Lossless Peak Current Sensing
- ♦ Monotonic Startup into Prebias Output (MAX8576/MAX8578)
- ♦ Startup Overvoltage Protection (MAX8577/MAX8579)
- ♦ Enable/Shutdown
- ♦ Fully Assembled and Tested

### Ordering Information

PART	TEMP RANGE	IC PACKAGE
MAX8576EVKIT	0°C to +70°C	10 μMAX®

µMAX is a registered trademark of Maxim Integrated Products, Inc.

# MAX8576 Component List

DESIGNATION	QTY	DESCRIPTION
		470µF, 35V aluminum electrolytic
C1, C2	2	capacitors
		Sanyo 35MV470WX
		10μF ±10%, 25V X5S ceramic
C3	1	capacitor (1206)
		Taiyo Yuden TMK316C106KL
		0.01µF ±20%, 10V X7R ceramic
C4	1	capacitor (0603)
		Kemet C0603C103M8RAC
	1	1μF ±20%, 35V X7R ceramic
C5		capacitor (1206)
		Taiyo Yuden GMK316BJ105ML
	C6 1	4.7µF ±20%, 6.3V X5R ceramic
C6		capacitor (0805)
		Taiyo Yuden JMK212BJ475MG
	1	0.1µF ±20%, 10V X7R ceramic
C7, C12		capacitors (0603)
		Kemet C0603C104M8RAC
C8	1	0.027µF ±10%, 50V X7R ceramic
		capacitor (0603)
		Kemet C0603C273K5RAC
		2200µF, 6.3V aluminum electrolytic
C9, C10	2	capacitors
		Rubycon 6.3MBZ2200M10X20

DESIGNATION	QTY	DESCRIPTION
C11	1	0.01µF ±20%, 25V X5R ceramic capacitor (0603) Kemet C0603C103M3PAC
C13	1	3300pF ±20%, 6.3V X7R ceramic capacitor (0603) Kemet C0603C332M9RAC
D1	1	100V, 250mA high-speed diode Philips BAS316 (SOD-323)
JU1	1	3-pin header
L1	1	1.8μH, 14A, 3.48mΩ inductor Panasonic ETQP2H1R8BFA
N1	1	30V, 12.5mΩ (max) n-channel MOSFET (SO-8) International Rectifier IRF7821
N2	1	30V, 3.7m $\Omega$ (max) n-channel MOSFET (SO-8) International Rectifier IRF7832
N3	1	n-channel MOSFET, 2N7002 (SOT23)
R1	1	6.04kΩ ±1% resistor (0603)
R2	1	5.11kΩ ±1% resistor (0603)
R3	1	12.4kΩ ±1% resistor (0603)
R4	1	1k $\Omega$ ±5% resistor (0603)

MIXIM

Maxim Integrated Products 1

# MAX8576 Component List (continued)

DESIGNATION	QTY DESCRIPTION	
R5	1	20kΩ ±5% resistor (0603)
R6	1	$2\Omega$ ±5% resistor (0603)
R7	1	10Ω ±5% resistor (0402)
R8	0	Not installed, shorted on PC board (0402)
U1	1	MAX8576EUB (10-pin μMAX)
None	1	Shunt (position 2)

## MAX8578 Component List

QTY	DESCRIPTION
	10μF ±20%, 25V X5R ceramic
1	capacitor (1210)
	Taiyo Yuden TMK325BJ106MM
	1µF ±20%, 25V X7R ceramic
1	capacitor (1206)
	TDK C3216X7R1E105M
	4700pF ±20%, 10V X7R ceramic
1	capacitor (0603)
	Kemet C0603C472M8RAC
	4.7µF ±20%, 6.3V X5R ceramic
1	capacitor (0805)
	Taiyo Yuden JMK212BJ475MG
	0.1µF ±20%, 10V X7R ceramic
1	capacitor (0603)
	Kemet C0603C104M8RAC
1	0.01µF ±20%, 25V X7R ceramic
	capacitor (0603)
	Kemet C0603C103M3RAC
	$47\mu$ F ±20%, 6.3V, ESR = 5m $\Omega$ , X5R
1	ceramic capacitor (1812)
	Taiyo Yuden JMK432BJ476MM
	0.01µF ±20%, 25V X5R ceramic
1	capacitor (0603)
	Kemet C0603C103M3PAC
	Not installed (optional, 47µF ±20%,
0	6.3V, ESR = $5m\Omega$ , X5R ceramic
	capacitor) (1812)
	Taiyo Yuden JMK432BJ476MM
1	1000pF ±20%, 25V X5R ceramic
	capacitor (0603)
	Kemet C0603C102M3PAC
1	100V, 250mA high-speed diode
	Philips BAS316 (SOD-323)
1	3-pin header
1	2.2μH, 7.3A, 9.8m $\Omega$ inductor
	Sumida CDEP104L-2R2
	1 1 1 1 1 1 0 1 1 1 1 1 1 1 1 1 1 1 1 1

### MAX8578 Component List

DESIGNATION	QTY	DESCRIPTION
N4	1	30V, $18m\Omega$ (max) n-channel MOSFET (SO-8) International Rectifier IRF7807Z
N5	1	30V, 12.5mΩ (max) n-channel MOSFET (SO-8) International Rectifier IRF7821
R9	1	6.04kΩ ±1% resistor (0603)
R10	1	2.49kΩ ±1% resistor (0603)
R11	1	12.4kΩ ±1% resistor (0603)
R12	1	2Ω ±5% resistor (0603)
R13	0	Not installed, shorted on PC board, resistor (0402)
U2	1	MAX8578EUB (10-pin μMAX)
None	1	Shunt (position 2)
None	1	MAX8576 EV kit PC board

#### **Quick Start**

#### **Recommended Equipment**

- One variable-DC power supply capable of supplying up to 13.2V at 3.5A
- One variable-DC power supply capable of supplying up to 5V at 100mA
- Digital multimeter (DMM)
- 5A load
- 12A load
- Ammeter (optional)

#### Procedure (MAX8576)

The MAX8576 EV kit is fully assembled and tested. Follow the steps below to verify board operation:

- Preset the variable-DC power supply to 12V. Turn off the power supply. Do not turn on the power supply until all connections are complete.
- Connect the positive lead of the 12V power supply to the VIN pad on the EV kit and connect the negative lead of the power supply to the GND pad on the EV kit.
- 3) Connect the positive lead of the DMM to the VOUT pad on the EV kit and connect the negative lead of the DMM to the GND pad on the EV kit.
- 4) Turn on the power supply.
- 5) Verify the voltage at VOUT is 1.8V ±5%.
- 6) Connect a 12A load between VOUT and GND.
- 7) Verify that the voltage at VOUT is 1.8V  $\pm$ 5%.

\_\_\_\_\_\_/N/XI/N

### **Component Suppliers**

SUPPLIER	PHONE	WEBSITE
Central Semiconductor	631-435-1110	www.centralsemi.com
International Rectifier	800-341-0392	www.irf.com
Kemet	864-963-6300	www.kemet.com
Panasonic	402-564-3131	www.panasonic.com
Philips	800-447-1500	www.semicondcutors.philips.com
Rubycon	408-467-3864	www.rubycon.com
Sanyo	619-661-6835	www.sanyo.com
Sumida	847-956-0666	www.sumida.com
Taiyo Yuden	408-573-4150	www.t-yuden.com
TDK	888-835-6646	www.component.tdk.com

**Note:** Indicate that you are using the MAX8576 when contacting these suppliers.

#### **Procedure (MAX8578)**

Follow the steps below to verify board operation:

- 1) Preset the variable-DC power supplies to 12V and 5V. Turn off the power supplies. **Do not turn on the power supplies until all connections are complete.**
- Connect the positive lead of the 5V power supply to the VCC1 pad on the EV kit, and connect the negative lead of the power supply to the GND1 pad on the EV kit.
- Connect the positive lead of the 12V power supply to the VIN1 pad on the EV kit, and connect the negative lead of the power supply to the GND1 pad on the EV kit.
- 4) Connect the positive lead of the DMM to the VOUT1 pad on the EV kit, and connect the negative lead of the DMM to the GND1 pad on the EV kit.
- 5) Turn on the 12V supply.
- 6) Turn on the 5V supply.
- 7) Verify the voltage at VOUT1 is 1.8V ±5%.
- 8) Connect a 5A load between VOUT1 and GND1.
- 9) Verify that the voltage at VOUT1 is 1.8V ±5%.

### Detailed Description

#### **Evaluating Other Output Voltages**

Both circuits come preset to a 1.8V output voltage. The output voltage of the MAX8576 is adjustable down to 0.6V and up to 0.9 x  $V_{IN}$ . To adjust the output voltage, place a  $\pm 1\%$  resistor at R3 with a value corresponding to the equation:

R3 = 
$$6040 \times \left( \frac{V_{OUT} + 0.01 + (0.5 \times R_{DC} \times I_{OUTMAX})}{0.59} - 1 \right)$$

where R<sub>DC</sub> is the resistance of the inductor. Refer to the MAX8576 data sheet for information on selecting the inductor, output capacitor, and feed-forward capacitor to optimize the circuit for different output voltages.

For the MAX8578 circuit, R11 can be calculated using the same method.

#### **Higher Input/Output Voltages**

The MAX8576 and MAX8578 circuits are targeted for 10.8V to 13.2V input voltages and 1.8V output voltages. However, the 9V to 24V input voltage range and an output voltage up to 0.9 x V<sub>IN</sub> is possible for IC evaluation. 30V rated MOSFETs must be installed if the input voltage is raised above 16V. Ensure that input and output capacitor voltage ratings are sufficient for the new operating voltages.

### \_Jumper Settings

#### **Jumper JU1 Function**

The MAX8576 circuit features an output shutdown mode. To shut down the output, place a shunt between pins 2 and 3 on JU1. For normal operation remove the shunt or place it on pins 1 and 2 of JU1 (default position).

#### **Jumper JU2 Function**

The MAX8578 circuit features an output shutdown mode. To shut down the output, place a shunt between pins 1 and 2 on JU2. For normal operation remove the shunt or place it on pins 2 and 3 of JU2 (default position).

#### Evaluating the MAX8577/MAX8579

To evaluate the MAX8577, carefully remove the MAX8576 and install the MAX8577. To evaluate the MAX8579, carefully remove the MAX8578 and install the MAX8579. All other components can remain the same.




Figure 1. MAX8576 EV Kit Schematic

4 \_\_\_\_\_\_ /I/XI/M




Figure 2. MAX8576 EV Kit Component Placement Guide—Component Side




Figure 3. MAX8576 EV Kit PC Board Layout—Component Side




Figure 4. MAX8576 EV Kit PC Board Layout—Layer 2




Figure 5. MAX8576 EV Kit PC Board Layout—Layer 3




Figure 6. MAX8576 EV Kit PC Board Layout—Solder Side

Maxim cannot assume responsibility for use of any circuitry other than circuitry entirely embodied in a Maxim product. No circuit patent licenses are implied. Maxim reserves the right to change the circuitry and specifications without notice at any time.